

Operating manual

Heidi Back 2.0 945048



Operating manual 02/06/2022

Version: V1.0

**LEGAL NOTICES** 

Owner and publisher

AUSTROFLAMM GMBH

Austroflamm-Platz 1 A- 4631 Krenglbach

Tel: +43 (0) 7249 / 46 443 www.austroflamm.com info@austroflamm.com

Edited by: Olivera Stojanovic Illustrations: Konstruktion

Text: Technical department (Austroflamm)

### Copyright

All Rights reserved. The contents of these instructions may be reproduced or distributed only with the consent of the publisher! Printing, spelling and typographical errors reserved.

# Contents

1	General information							
	1.1	Copyright	6					
2	Purpos	e of the manual	7					
	2.1	Storing the manual	7					
	2.2	Structure of the manual	7					
	2.3	Representations used	7					
	2.4	Version control	7					
	2.5	Abbreviations	8					
3	Safety.		9					
	3.1	Importance of the safety instructions	9					
	3.2	Warning of sources of danger						
	3.2.1 3.2.2	General safety instructions						
4		t overview						
	4.1	Intended use						
	4.2	Identification of the product						
	4.3	Energy label						
	4.4	Positioning of the nameplates	13					
5	Technic	cal data	14					
	5.1	Technical data according to Regulation (EU) 2015/1185 and delegated Regulation (EU) 2015/1186	14					
	5.2	General specifications	16					
	5.3	Data for the chimney/flue dimensioning	16					
6	Transp	ort, handling and storage	17					
	6.1	Transportation	17					
	6.2	Storage	17					
7	Require	ements at the installation location	18					
	7.1	Safety distances to be observed						
	7.2	Combustion air	18					
	7.3	Chimney requirements	18					
	7.4	Floor load-bearing capacity	18					
	7.5	Floor condition	18					
	7.6	Room of installation	18					
8	Fuel m	aterial/-quantity	19					
	8.1	Fuel						
	8.2	Fuel quantity						
9		tion						
7	9.1	Risks and dangers						
	9.1 9.2	Execution						
	9.2 9.2.1	Mounting the hob						
	9.2.2	Rearranging the flue pipe connection						

	9.2.3 9.2.4	Softlock conversion	
	9.2.4 9.2.5	Mounting the Keramott	
	9.2.6	Installing the log drawer	
10	Air+ in:	stallation and operation	34
	10.1	Removing the rotary control unit	34
	10.2	Attaching the firebox temperature sensor	34
	10.3	Converting the rotary control unit	35
	10.4	Installing the control unit	35
	10.5	Installing the DC plug	36
	10.6	Electrical connection of the controls	36
	10.7	Mounting the cover	37
	10.8	How the "AIR+" automatic combustion control works	37
	10.9	Spare parts	39
11	Setting	JS	41
	11.1	Door hinges	41
	11.2	Adjusting the door spring	42
12	Commi	issioning	43
	12.1	Initial Commissioning	43
	12.2	Balanced Flue Operation	43
13	Operat	iion	44
	13.1	Before heating up	44
	13.2	Making fire correctly	44
	13.3	Heating in the transition period	45
14	Mainte	nance	46
	14.1	Changing the seal on the door	46
15	Cleanir	ng	47
	15.1	Cleaning the stove, flue gas ducts and flue pipe	47
	15.2	Emptying the ash box	47
	15.3	Cleaning the door window	48
	15.4	Cleaning surfaces	48
16	Help		49
	16.1	Firebox lining	50
	16.2	What to do in the event of a chimney fire	50
	16.3	What to do in the event of faults	50
17	Access	ories	51
18	Spare p	oarts	52
19	Dismar	ntling	57
	19.1	Removing the side cladding	
20	Dispos	al	59
21	Guaran	ntee / warranty	61

22	Data processing	62
23	Start up log	63
24	Service Report	64

### 1 General information

You have decided in favor of an Austroflamm stove.

#### Congratulations on your decision and thank you for your trust.

Correct operation and care are essential for trouble-free operation and long service life.

The information in this manual is of a general nature. National and European standards, local and building regulations, together with fire regulations must be complied with.

Read these instruction through carefully before installation and operation. No liability or warranty claims apply for damage incurred by failure to follow this manual.

Please observe the instructions in the individual sections.

This manual is a component part of the stove. It includes all the important information for both the dealer and the customer.

Personally hand over this manual to the owner of the stove together with an introduction to the system (heating operations).

In the following list we give you an overview of which sections are important for whom:

Dealer	End customer				
Complete instructions	General information [▶on page 6]				
	Purpose of the manual [▶on page 7]				
	Safety [▶on page 9]				
	Product overview [▶on page 11]				
	Technical data [▶on page 14]				
	Requirements at the installation location [>on page 18]				
	Fuel material/-quantity [▶on page 19]				
	Settings [▶on page 41]				
	Commissioning [▶on page 43]				
	Operation [▶on page 44]  Maintenance [▶on page 46]				
	Cleaning [▶on page 47]				
	Help [▶on page 49]				
	Accessories [▶on page 51]				
	Spare parts [▶on page 52]				
	Dismantling [▶on page 57]				
	Disposal [▶on page 59]				
	Guarantee / warranty [▶on page 61]				
	Data processing [>on page 62]				
	Service Report [▶on page 64]				

### 1.1 Copyright

All Rights reserved. The contents of these instructions may be reproduced or distributed only with the consent of the publisher! Printing, spelling and typographical errors reserved.

# 2 Purpose of the manual

This manual is a component part of the stove and is intended to contribute to the stove being safely installed and maintained.

### TIP

Please read this manual before using the stove for the first time.

### 2.1 Storing the manual

Store this manual in case you need it. A current version of the manual can be found online at our homepage www.austroflamm.com.

#### 2.2 Structure of the manual

The table of contents can be found on page 3.

Illustrations in this manual may differ from the delivered product.

#### 2.3 Representations used

The following representations are used in this manual:

#### Steps with mandatory adherence to the sequence

- ✓ Prerequisite
- 1) Step 1
- 2) Step 2
- 3) .....
  - ⇒ Intermediate result / additional information
- ⇒ Result

#### Steps and bullet points without mandatory sequence

- ....
- ....
  - ....
  - ....

#### **Cross-references**

See Technical Data [▶on page 14]

#### **Useful tips**

#### TIP

#### Fuel

Use only the recommended fuel!

#### 2.4 Version control

We update our manuals on a continual basis. The current version can be found at our homepage www.austroflamm.com.

# 2.5 Abbreviations

Abbreviation	Meaning
Air+	Automatic combustion control for stoves
HMS	Heat Memory System
ST	Stoves

# 3 Safety

In this manual we give you numerous safety instructions for the safe operation of your stove. These instructions are characterized differently as follows, depending on their importance:

### 3.1 Importance of the safety instructions

### **NOTICE**

Particular behaviour and/or activities that are required for safe working. Failure to follow this can result in material damage.

# **⚠** CAUTION

Possible dangerous situation (light or minor injuries and material damage).

# **⚠** WARNING

Possibly imminent danger to life and health of persons (severe injuries or death).

# **⚠** DANGER

Immediately imminent danger to life and health of persons (severe injuries or death).

### 3.2 Warning of sources of danger

#### 3.2.1 General safety instructions

- The information in this manual represents generally applicable standards and rules. National and European standards, local and building regulations, together with fire regulations must also be complied with.
- Before operating your stove, carefully read through the entire manual and observe the instructions and warnings.
- Only approved transport aids with sufficient load-bearing capacity may be used to transport your stove.
- Caution varnish is not an anti-rust protection!
- Burn only the fuel listed and approved in the section.
- It is strictly forbidden to burn or introduce highly flammable or explosive substances, such as empty aerosols and the like, into the firebox or to store them in the immediate vicinity of your stove due to the risk of explosion.
- No loose or easily flammable items of clothing should be worn when laying the fire.
- Please note that placing non-heat-resistant objects on, or near, the stove is forbidden.
- Do not place any items of laundry on the stove to dry. Laundry racks or the like must be placed at a sufficient distance from the stove. (Fire hazard!)
- This stove is not a slow-burn fire.
- While your stove is in operation, it is forbidden to process highly flammable or explosive substances in the same room or in adjoining rooms.
- The stove must only be operated with the doors closed.
- The door and all the stove's control devices must be closed when the stove is not in operation.

• Please note that the surfaces of this stove heat up considerably during operation. We recommend that you use the protective glove supplied to operate your stove.



• Please alert children to these dangers, and keep them away from the stove when it is operating.

### **⚠** DANGER

### Danger of overheating

To prevent damage you must **NEVER** operate your stove with a greater quantity of fuel than the quantity given in these instructions, either during its initial commissioning or every time you subsequently light it up again!

• Your stove is not suitable for use as a ladder or a stand.

#### 3.2.2 Special types of danger and personal protective equipment

For certain activities such as installation/dismantling, particular care must be taken that the following safety equipment is worn:

Safety gloves
Safety shoes

### 4 Product overview

### 4.1 Intended use


The Austroflamm stove described in this manual is manufactured and tested with a type A1 self-closing and locking door under EN test EN 13240.


# **NOTICE**


Operation is only permissible with closed/bolted door.


### 4.2 Identification of the product

In the following illustrations we give an overview of the most important dimensions and the nameplate positioning.













Fig. 1: Dimensions

1) Open (+) and closed (-) (primary/secondary air control-



 $\label{eq:baseline} \textbf{b}$  Fig. 2: Safety distances (a, b, c) / air controller

# 4.3 Energy label





Fig. 3: Energy label

# 4.4 Positioning of the nameplates

Here we show where you can find the nameplate. You can find a copy of the nameplate of your stove on the back of this manual.



The type plate is located in the firebox below the ash box.

Fig. 4: Nameplate

### 5 Technical data

As a type 1 stove, a connection to a chimney already occupied with other solid-fuel stoves and ovens is possible provided that the chimney rating under DIN 4705 - part 3, does not contravene this.

# 5.1 Technical data according to Regulation (EU) 2015/1185 and delegated Regulation (EU) 2015/1186

#### Contact details for the manufacturer or their authorized representative

Manufacturer:	Austroflamm GmbH
Contact:	-
Address:	Austroflamm-Platz 1
	4631 Krenglbach
	Austria

#### **Appliance details**

Model identification(s):	Heidi Back
Equivalent models:	-
Test reports:	DBI F 18/10/0609
Applied harmonized standards:	EN 13240
Other standards/technical specifications applied:	-
Indirect heating function:	no
Direct heat output:	7.0 kW
Indirect heat output¹:	-

### Properties for operation with the preferred fuel

Space heating annual use efficiency $\eta_{\mbox{\tiny s}}$ :	72.0 %
Energy efficiency index (EEI):	108

#### Particular precautions for assembly, installation or maintenance

Described in the individual sections of the operating manual.

Fuel	Preferred fuel (only one) <sup>2</sup> :	Other suitable fuel(s) <sup>3</sup> :	ηs [x%]:		e heatir at nom cy (*)			sions	e heatir at mini efficien	imun	n
	. , .			PM	OGC	CO	NOx	PM	OGC	CO	NOx
				[x] m	g/Nm³	(13%	O2) <sup>5</sup>	[x] mg O2) <sup>6</sup>	g/Nm³	(13%	6
Log, moisture content ≤ 25 %	yes	no	72.0	30	33	728	113	-	-	-	-
Compregnated laminated wood,	no	no	-	-	-	-	-	-	-	-	-
Moisture content < 12 %											
Other woody biomass	no	no	-	-	-	-	-	-	-	-	-
Non-woody biomass	no	no	-	-	-	-	-	-	-	-	-
Anthracite and dry steam coal	no	no	-	-	-	-	-	-	-	-	-
Coking coal	no	no	-	-	-	-	-	-	-	-	-
Semi-coke	no	no	-	-	-	-	-	-	-	-	-

Bituminous coal	no	no	-	-	-	-	-	-	-	-	-
Lignite briquettes	no	no	-	-	-	-	-	-	-	-	-
Peat briquettes	no	no	-	-	-	-	-	-	-	-	-
Briquettes made from a mixture of fossil fuels	no	no	-	-	-	-	-	-	-	-	-
Other fossil fuels	no	no	-	-	-	-	-	-	-	-	-
Briquettes made from a mixture of biomass and fossil fuels	no	no	-	-	-	-	-	-	-	-	-
Other mixture of biomass and solid fuels	no	no	-	-	-	-	-	-	-	-	-

<sup>(\*)</sup> PM = dust, OGC = organic gaseous connections, CO = carbon monoxide, NOx = nitrogen oxide (\*\*) Only required when using correction factors F(2) or F(3).

### Properties for exclusive operation with the preferred fuels<sup>7</sup>

Specification	Symbol	Value	Unit	Specification Symbol Value	Unit					
Heat output				Thermal efficiency (fuel efficiency) (based on the NCV						
Nominal heat efficiency	Pnom	7.0	kW	thermal efficiency (fuel efficiency) at nominal heat efficiency	%					
Minimum heat output (standard value)	Pmin	-	kW	thermal efficiency (fuel efficiency) at minimum heat efficiency (standard value)	%					
Auxiliary power co	onsumption	on		Type of heat output/room temperature control						
At nominal heat efficiency	elmax	-	kW	single-level heat output, no room temperature control	yes					
At minimum heat output	elmin	-	kW	two or more manually adjustable levels, no room temperature control	no					
In standby condition	elSB	-	kW	Room temperature control with mechanical thermostat	no					
Pilot flame power	requirem	ent		with electronic room temperature control	no					
Pilot flame power requirement	Ppilot	-	kW	with electronic room temperature control and day- time regulation	no					
(if present)										
				with electronic room temperature control and weekday regulation	no					
				Other regulation options						
				(Multiple answers possible)						
				Room temperature control with presence detection	no					
				Room temperature control with open window detection	no					
				with remote control option	no					

<sup>&</sup>lt;sup>1</sup> There is no entry for fireplaces without water-carrying components.

<sup>&</sup>lt;sup>2</sup> Values for annual use efficiency and emissions must be given here for the preferred fuel.

<sup>&</sup>lt;sup>3</sup> Values for annual use efficiency and emissions must be given here for all other suitable fuels.

<sup>&</sup>lt;sup>4</sup> Corresponds to partial load heat output as per EN 16510

<sup>&</sup>lt;sup>5</sup> Specification in mg/m³ for heated filter method (in compliance with Annexe III, number 4, letter a, section i, point 1) or g/kg for measurement in dilution tunnel (in compliance with Annexe III, number 4, letter a, section i, point 2 and 3.)

# 5.2 General specifications

Technical data	Basic appliance
Height [mm]	1066
Width [mm]	620
Depth [mm]	405
Weight [kg] steel/ceramic/soapstone	173 / - / -
Flue pipe outlet, diameter [mm]	130
Nominal heat efficiency [kW] It EN test EN 13240	7
Heat output, minimum [kW]	3.5
Maximum heat output [kW]	9
Space heating capacity, at least (depending on the building insulation) [m³]	82
Maximum room-heating capacity (depending on the building insulation) [m³]	210
Minimum clearance from non-flammable materials [mm]	50
Max. amount of fuel to be deposited [kg] (wood/briquettes)	1.7

# 5.3 Data for the chimney/flue dimensioning

Exhaust gas values for the multiple occupancy of the chimney (according to DIN 4705 Part 3) or rating of the chimney (according to DIN 4705 Part 2)	
Flue gas mass flow [g/s]	6.41
Flue gas temperature [°C]	262
Minimum feed pressure at nominal heat output [Pa] closed	10
at 0.8 times nominal heat output [Pa]	8
Safety distances a, b, c [mm]	1300 / 200 / 200

<sup>&</sup>lt;sup>6</sup> Specification mg/m³ for heated filter method (in compliance with Annexe III, number 4, letter a, section i, point 1) or g/kg for measurement in dilution tunnel (in compliance with Annexe III, number 4, letter a, section i, point 2 and 3.)

<sup>&</sup>lt;sup>7</sup> Specifications are made here for the preferred fuel only.

# 6 Transport, handling and storage

# 6.1 Transportation



Fig. 5: Crate

Immediately checked the goods delivered for completeness and damage in transit.

Before installing the stove, check that all movable parts are working. Any defects before the installation of the stove must be reported.

Transport is with a crate. The crate facilitates transport of the stove using a lifting truck or forklift.

Remove the crate and dispose of it appropriately.

### 6.2 Storage

The stove must be stored in a dry room/warehouse. Protect against dirt, heat and moisture.

The following illustrations are attached to the crate and must be observed:








- Fragile always place upright protect against moisture and store dry.
- Remove and dispose of packing material in an environmentally friendly manner.
- The crate can be disposed of in the separate collection for packaging. Local disposal regulations must be observed.

# 7 Requirements at the installation location

### 7.1 Safety distances to be observed



Safety distances to be observed (minimum clearances - see also type plate).

- a) 1300 mm (at the front in the radiation area)
- b) 200 mm (at the sides in the radiation area)
- c) 200 mm (rear)

Fig. 6: Safety distances

#### 7.2 Combustion air

An adequate supply of combustion air must be provided during operation. With a modern very thick building shell it can happen that the combustion air supply is not guaranteed for balanced flue operation or that the draft behavior is impaired. In this case an adequate supply of combustion air must be provided. Your Austroflamm specialist dealer will be happy to advise you.

#### TIP

Ensure that combustion air openings are not closed!

### 7.3 Chimney requirements

When connecting the flue pipes to the chimney, national and/or local safety regulations must be complied with. Your Austroflamm stove is fitted at the factory with a flue outlet at the top (diameter 130 mm). The connection can, as described in these instructions, be rearranged to the bottom. When connecting with other pipe diameters the approval of your responsible chimney sweep is required. The flue pipe connection and flue pipe transitions must be sealed accordingly. Your Austroflamm specialist dealer knows the guidelines and will be happy to advise you. For your own safety the connection of the flue pipe must be carried out by a technically competent person.

### 7.4 Floor load-bearing capacity

Before installing, verify whether the load-bearing capacity of the substructure can withstand the weight of your Austroflamm stove.

#### 7.5 Floor condition

In the radiation area of the pane (in front of the stove), the floor must not be combustible.

#### 7.6 Room of installation

Note that the room in which the stove is installed must have at least one door / one window leading to the outside, or be directly connected to such a room. For balanced flue operation, other heating appliances and extractor hoods must not be operated together with this heating appliance as part of the room air system.

# 8 Fuel material/-quantity

#### 8.1 Fuel

#### Wood

Many of our native types of wood can, after being appropriately dried, be burnt CO2-neutral in heat-producing appliances. Wood stands out because it grows again, can be sustainably harvested, requires little or no extra external energy to be invested in the fuel, and has a short journey from the producer to the consumer, which provides an optimal climate balance.

The most common types of wood to use in the stove are beech, yoke elm, birch, larch, spruce and pine. The most important criterion for burning in a heat-producing appliance is that the fuel has been sufficiently dried through. For this purpose the prepared pieces of log should be stored for at least two years. The legislator stipulates a maximum water content of 20%. That is still however a lot of water sitting in the capillaries of the wood. A piece of firewood only becomes good when its water content comes to a maximum of 12 to 13%. The differences in combustion behaviour are striking and clearly detectable even by the layman.

Types of wood other than the ones referred to above are also suitable for burning. However each heat-producing appliance should be checked for how their use affects combustion behaviour. Oak for example burns with a rather shorter flame and more embers. Oakwood catches fire with greater difficulty, and due to hardness of the wood it is not split as well (small) as other types of wood, which again has a negative effect on combustion behaviour. It is however a good energy source, and, correctly processed, also suitable as firewood.

Softwoods (fir, pine, spruce) should if possible be mixed with hardwood. Softwoods have a higher proportion of tannin, which leads to more deposits in the heat-producing appliance, the connecting pipes and the chimney. If only softwood is burnt, this can lead more quickly to a build-up of shining soot. Mixing with hardwood (for example, beechwood) reduces this effect.

The size of your heat-producing appliance's combustion chamber will dictate whether your firewood is 25cm, 33cm or 50cm in length. 50cm pieces of log should preferably dry for somewhat longer (lain down for three years or more), because wood is dried out mainly by the leakage of water from the capillaries - and that simply takes time. And the path from inside to outside in a 50cm-long piece of log is twice as long as in a 25cm-long piece of log. The important thing is that the wood is well split. This means that the circumference of a piece of log (once all sides are measured around the cutting point) must be a maximum of 15-25cm. Pieces of wood cut to this size dry more easily - above all, however, they give the fire (the temperature) a greater attack area and thus make it easier to evolve gas and thus to burn. Also the quantity of fuel can be better measured out. Thanks to their outstanding levels of efficiency, modern heat-producing appliances require just a fraction of the amount of wood of earlier stoves. Here smaller pieces of log can be placed according to the manufacturer's specifications - large pieces of log often exceed the maximum specified quantity with just a single piece.

Not everyone has a hygrometer at home for determining the water content in wood, particularly when good reliable units cost several hundred euros. However you can make a good estimate of how suitable your fuel is by carefully observing combustion behaviour. A "good" wood fire will only smoke briefly in the ignition phase, hardly at all after that. It will burn with a light (yellow to orange-coloured) long flame. Little residue will occur in the combustion chamber, most of it disappearing again when the fire is fully developed. Another good criterion for assessing whether a piece of log is suitable for combustion is its weight. Most manufacturers also specify the amount to be laid in kg/weight. Example: a piece of beechwood 33cm in length with a circumference of approx. 20cm weighs approx. 1kg when it is suitable (dry enough) for burning. Therefore 25cm in length gives approx. 750 grammes, and 50 cm in length approx. 1.5kg.

Please observe at all times the maximum specified amount to be laid, even when putting on more wood! Otherwise your fire will not provide the desired efficiency - but above all considerable damage may be caused to your appliance, to gaskets and material and to the flue gas duct.

The wood may only be burnt untreated. NEVER burn treated woods, not even wood processed with natural substances or organic glazes. Wood waste does not belong in the stove!

#### **Wood briquettes**

Many people like wood briquettes as a fuel because they require less storage space than wood, can be stocked or sold in small quantities and - at least at first glance - make less work than wood. Within the scope of production, the quality of briquettes is consistent. Wood briquettes do not need to be stored for a long time to be dried out. Due to the raw material (unrefined chips) and the production process they have an already defined residual moisture.

If wood briquettes are designated as a suitable fuel, then this still only applies to this fuel, NOT for coal-, paper-, bark- or other pressed items, such as pellets.

In spite of various standardizations and many advertising promises, there are also considerable differences in quality in wood briquettes. But even with good fuel quality, combustion behaviour is different from that of unrefined log. And not every wood briquette burns equally well in every stove. Before you decide on a particular variety and perhaps even store this up in larger quantities, you should extensively test the wood briquettes under various draft conditions. Most suppliers keep "test packages" for this purpose that can be purchased at preferential prices to test out and compare with one another the various types offered.

#### TIP

When burning wood briquettes, the maximum quantity specified in these instructions must also be observed. The quantity must not be exceeded.

As the wood is pressed and thus has little spatial volume for the same weight, modern heat-producing appliances with a low placement quantity often have "little fire heaps" occur, leading one to wonder whether a fire can burn at all with so little fuel. Nevertheless you must never exceed the maximum placement, because that would cause damage. Many wood briquettes change during the temperature increase when burning, by "opening up". This should not worry you as it is normal. When inserting wood briquettes make sure that this expansion as far as possible does not press not in the direction of the window, as otherwise this will get very dirty.

In principle you should not insert wood briquettes as one piece, but rather break them at the layer thicknesses, which are usually visible in slices, and place smaller pieces in the combustion chamber, not in an interlocking manner, but randomly. This way you will ensure that the combustion air reaches more burning material and flows around it better. Wood briquettes require a stronger air current, an expert eye and perhaps a bit more patience, until you get the knack of it. Since less volume is available (although the same mass, it takes less space up), the fire is generally smaller and does not burn so high and vivaciously as when burning log. When wood briquettes alone are burnt, this therefore generally leads to haziness in the combustion chamber, as well as on the stove window. Not all areas of the combustion chamber have the same temperature applied to them as when unrefined wood is burnt, which is why these deposits occur. It may be that with one variety of wood briquettes more deposits occur, whereas with another variety none at all. This suggests trying out various varieties to determine the suitable fuel for your heat-producing appliance. If you would really like to use wood briquettes, but don't get on quite well with them, then it may also help to mix the fuel. That means: Burn wood briquettes and unrefined log in the mixture ratio that achieves a good burning result for your heat-producing appliance.

Wood briquettes must also be stored dry. In general it can be said that pressed items with a hole in the middle usually burn better. Soft wood briquettes are to be preferred and are often more suitable than hard wood briquettes.

#### Approved fuel

Dry, well-stored, unrefined log (preferably hardwood) and/or wood briquettes.

Round wood must be split at least once so that it lights better. The diameter of the split piece of wood must not exceed 7 cm.

#### **Explosive substances**

It is strictly forbidden to burn or introduce highly flammable or explosive substances (empty aerosols and the like) into the firebox or to store them in the immediate vicinity of your stove. Risk of explosion!

#### Fuel

Only burn the recommended fuel.

#### Clean combustion

The firewood must be dry (rel. wood moisture < 15 %) and untreated. Furthermore the correct quantity of firewood must be burnt in order to achieve a clean, low-emission combustion.

### 8.2 Fuel quantity

#### Maximum fuel quantity

Your Austroflamm stove is designed for maximum efficiency: see Technical Data section. Too great a quantity of fuel can lead to overheating and damage to your Austroflamm stove!

Maximum amount of fuel to be deposited: 1.7 kg wood or briquettes.

### **NOTICE**

#### Overheating

Too great a quantity of fuel can lead to overheating and damage to your Austroflamm stove

#### **NOTICE**

To avoid damage you must **NEVER** operate your Stove a greater quantity of fuel than that specified in this manual!

### 9 Installation

Installation must only be carried out by an authorized specialist company.

Before installing the stove, check that all movable parts are working. Any defects must be reported before the installation.

In the following sections we will give you information on

- the integration or attachment of appliance parts
- the rearrangement of the flue pipe connection
- The connection of the combustion air supply, and on
- other important facts relating to the installation.

### 9.1 Risks and dangers

### Protective equipment

The following protective equipment must be used:

Type of protective equipment	
	Safety gloves
	Safety shoes

### 9.2 Execution

#### 9.2.1 Mounting the hob




Fig. 7: Adjusting the rubber cushions

- 1) Adjust rubber cushions (1) to 0.5 mm.
- 2) Screw adjusting screws (2) in or out as required.




Fig. 8: Attaching the hob




Fig. 9: Transition

- 3) Attach the small hob (1) and fix from below using the nuts.
  - ⇒ Should you have difficulty in fixing the nuts during this stage, remove the side cladding and rear panel from the stove. Proceed as described in the section Removing the side cladding [▶on page 57].
- 4) Place the large hob (2) on to the rubber cushions.

- 5) The transition between the small and the large hob must be straight and not show any difference in height.
  - ⇒ If the transition is not straight, adjust the adjusting screws (2) and/or the rubber cushions (1) to the correct height.
- 6) If the side cladding was removed, remount it.

#### 9.2.2 Rearranging the flue pipe connection




Fig. 10: Removing the hob

- 1) First remove the hob.
- 2) Detach side cladding and the rear panel. Proceed as described in the section Removing the side cladding [on page 57].




Fig. 11: Removing the perforated cut-out




Fig. 12: Removing the radiation protection




Fig. 13: Remove cover and bracket

3) Use a saw to remove the perforated cut-out on the rear panel.

- 4) Undo the screws and remove the radiation protection (1).
- 5) Use a saw to remove the perforated cut-out on the radiation protection.

- 6) Remove cover with seal (1) on the back.
- 7) Remove bracket with seal (2).




Fig. 14: Replacing cover and bracket




Fig. 15: Setting rubber cushions and adjusting screws




Fig. 16: Rubber cushions (1) to 0.3 mm




Fig. 17: Adjusting screws (2) to 0 mm

8) Replace parts and reinstall.

- 9) Adjust rubber cushions (1) to 0.3 mm.
- 10) Completely screw in adjusting screws (2) to 0 mm.




Fig. 18: Mounting the radiation protection




Fig. 19: Mounting the rear panel and side cladding

11) Remount radiation protection.

- 12) Mount the outer rear panel
- 13) Mount the left and right side cladding.




Fig. 20: Attaching the hob

14) Place the new hob on to the rubber buffers.

### 9.2.3 Softlock conversion





Fig. 21: Loosening the screws

- 1) Carefully remove the hob.
- 2) Loosen screws.



3) Loosen screws on the inside on the right.






Fig. 23: Detaching the right-hand side cladding

4) Detach right-hand side cladding.



5) Open door.

Fig. 24: Opening the door



6) Detach wooden handle from original door handle.




Fig. 26: Mounting the wooden handle

7) Mount wooden handle on the new door mechanism.




Fig. 27: Mounting the new door handle




Fig. 28: Mounting adapter plate and catch

8) Mount new door handle in the original position.

- 9) Mont the adapter plate (1).
- 10) Mont the catch (2) on the adapter plate (1).



Fig. 29: Engaging the catch




Fig. 30: Closing the door

11) Engage catch as illustrated.

12) Close door slowly. In the process, make sure that the door engages the catch correctly.




Fig. 31: Side cladding mounted

# 9.2.4 Installing the HMS




Fig. 32: Removing the radiation protection

- 13) Remount the right-hand side cladding.
- 14) Attach hob.

- 1) First the hob must be removed and the side cladding detached. Proceed as described in the section Removing the side cladding [on page 57].
- 2) Undo the screws and remove the radiation protection (1).
  - After the HMS bricks have been installed, the radiation protection is no longer installed.




Fig. 33: Removing the lid






Fig. 34: Mounting HMS holder and HMS brick

3) Undo all the screws from the lid and remove the lid.

- 4) First mount the HMS holders on the side.
- 5) Attach the HMS brick to the HMS holder.
- 6) Repeat both steps on the other side of the stove.





7) Mount the HMS holders as shown on the rear of the stove and attach the HMS bricks to the holders.




Fig. 36: Attaching side cladding, lid and hob

8) Remount side cladding and lid and attach the hob.

#### 9.2.5 Mounting the Keramott




Fig. 37: Keramott

Numbering = installation sequence

#### 9.2.6 Installing the log drawer

# **NOTICE**

If you have installed Air+ or would like to use it, it is not possible to use the log drawer together with Air+.




Fig. 38: Removing the supply air flange




Fig. 39: Parts changed over




Fig. 40: Inserting the log drawer

- 1) First the side cladding and the rear panel must be detached. Proceed as described in the section Removing the side cladding [on page 57].
- 2) Remove supply air flange (1).
  - ⇒ With the log drawer appliance part, the supply air flange can be converted to the rear. If this is not desired, then as a consequence it will not be required and can be removed.
- 3) Remove side part (2) and if necessary mount the supply air flange (1) in this location.
- 4) Mount the side part (2) below in the place of the supply air flange.

- 5) Reattach side cladding, rear panel, lid and hob.
- 6) The log drawer can now be inserted.

# 10 Air+ installation and operation

# 10.1 Removing the rotary control unit




Fig. 41: Remove rotary control unit

1) Please remove both hexagonal nuts and take the rotary control incl. the complete rod system (82 mm and 92 mm) out of the air box. Both rods will be replaced by new ones.

### 10.2 Attaching the firebox temperature sensor





Fig. 42: Fixing the firebox temperature sensor

- 1) In order to be able to install the firebox temperature sensor, firstly the left side part of the stove must be removed.
- 2) Then the temperature sensor with the sensor sleeve can be mounted instead of the cover plate.

### 10.3 Converting the rotary control unit



### **NOTICE**

Before dismounting, mark the position of the wooden handle as shown in the illustration.

- 1) Dismount the rotary control unit, as shown in the picture below.
- 2) Remove the shim.
- 3) Then reassemble the rotary control unit.

### **NOTICE**

The grub screw must be removed in order to be able to dismount the rotary control unit. Afterwards the grub screw must be reinstalled.





Fig. 43: Rotary control unit conversion

#### 10.4 Installing the control unit



1) Insert the 125 mm hexagon rod supplied into the air box and turn fully counterclockwise.





Fig. 44: Control unit


- 2) Then slide the magnetic driving plate onto the hex
- 3) Now slide the preassembled unit (motor incl. controls) on to the hex rod and fix the unit on to the air box using the two Torx screws shown, which must be removed beforehand.
- 4) Then mount both the universal cardan joints included in the set and the rotary control unit.
  - ⇒ Ensure that the rotary control unit is in the position shown above before mounting.
- 5) Then fix the screws on the cardan joints with the rod system!

#### 10.5 Installing the DC plug



1) Guide the power cable with plug through the rear panel and fasten it as per the picture.

#### 10.6 Electrical connection of the controls





- 1) Make sure that all the components are correctly connected.
- 2) Plug the mains cable plug into the electrical point. Test the air control system and set the minimum and maximum motor position calibration process.
- 3) Wait approximately three minutes after the plug has been plugged in and then check whether the air control system (rotary knob) has fully opened and closed by itself again after these three minutes have expired.
- 4) The air control system (rotary knob) should be completely closed again after the calibration process.
- 5) The air control system (rotary knob) did not completely open and close during these three minutes. Therefore check the following:
- Plug correctly connected to the mains.
- Air control system is functioning. Any LED display lights are flashing.
- All components are correctly connected: check whether all connectors are correctly connected.
- Is the temperature scale in the combustion chamber above the ambient temperature? If the stove is warm due to a previous firing process or if the stove is just warming up, this will be detected by the air control system. Therefore the calibration process will be prevented and the air control system will switch straight to combustion phase 1.
- Check the rotary knob. It should be capable of being turned against a slight resistance. Otherwise the rotary knob and all connected components must be checked. Despite the automatic air control system the position of the damper doors can be manually adjusted.

# 10.7 Mounting the cover




Fig. 45: Mounting the cover

#### 1) Then mount the cover

# 10.8 How the "AIR+" automatic combustion control works

#### General

The "AIR+" combustion control only reacts to differences in the firebox temperature. The appropriate information is transmitted from the firebox temperature sensor to the controls. Should the firebox temperature sensor be defective, unplugged or have a fault, the control unit automatically goes into fault mode with pre-programmed control opening and does not change this position until the fault is resolved.

#### Operation

Operation of the "AIR+" combustion control consists of the following phases:




Fig. 46: Phase

#### **Calibration**

Calibration of the controls is carried out when the controls are connected to the mains. In doing so, the damper door is completely opened 1x and closed again. If the stove has previously been manually controlled in unpowered operation, then the damper door position is recalibrated when connected to the mains. Should a rise in temperature be detected during calibration, then the stove immediately switches to ignition phase 1.

After each combustion cycle the control system carries out a new calibration. This serves to ensure the correct synchronization between the damper door and the rotary control unit.

#### Off

In this state the damper doors are closed. In the event of a rise in temperature, the stove switches to ignition phase 1.

#### Ignition phase 1

The damper doors are completely opened. After about 15 minutes, the switch to ignition phase 2 takes place. If within about 30 minutes no fire is detected, the the control system switches into the ember phase.

#### Ignition phase 2

The damper doors are not completely opened. After about 5 minutes, the switch to combustion phase 1 takes place. If within about 30 minutes no fire is detected, the the control system switches into the ember phase.

#### Combustion phase 1

The damper doors are controlled as a function of the firebox temperature.

#### Combustion phase 2

The damper doors are controlled as a function of the firebox temperature.


#### Stoking phase

The damper doors are completely opened once more in order to fan the embers for the stoking process. When stoked up with wood, the flame temperature rises and the system switches to combustion phase 1. Otherwise after a certain length of time the system switches to the ember phase.

### **Ember phase**

Damper doors are opened approximately halfway in order to maintain the firebed. If the temperature in the combustion chamber rises above a certain point, the system switches to the stoking phase and then to combustion phase 1. Otherwise the system switches to the OFF phase. Calibration is carried out before positioning into the off phase.

# 10.9 Spare parts




Item no.	Qty	Item	ltem no.
1	2	Cheesehead bolts with socket head (very low head) M4x10	724701
2	1	Ring magnet DM10.1/9.5 H 6.4mm	724719
3	1	switch drive	724720
4	1	Airmaster Mainboard	724726
5	2	Universal joint with thread	724826
6	1	KS DC socket	724828
7	1	Power supply unit	724829
8	1	KS actuator AIR+	724930
9	1	Belimo anti-rotation clip	724880
10	1	AIR+ flame temperature sensor cable kit	728274
11	1	FTS	778675
12	1	Sensor tube, closed	779022
13	1	Cable binder 2,8x200	940274
14	1	Mounting instructions	718502-92
15	1	Counter-sunk head with hex M4x6 718539-92	
16	2	Taptite SKS M5x8	718539-92
17	2	Taptite ISR-LKS M3x5	718567-92
18	4	Fillister-head screw with hex M3x5 718641-92	

ltem no.	Qty	Item	Item no.
19	1	Driving plate	724689-92
20	1	Controller drive shaft 2	724702-92
21	1	Controller drive shaft 3	724703-92
22	1	Motor magnet adapter	724715-92
23	1	Aperture control unit	724716-29
24	1	Mainboard support sleeve	724717-29
25	1	Cover	724718-29
26	2	Spacer 5x7x6	772792-29

# 11 Settings

# 11.1 Door hinges



- 1) To adjust the door, the hob must be removed and only the left side cladding detached. Proceed as described in the section Removing the side cladding [> on page 57].
- 2) Using the screws (1) the door can be adjusted up, down, left and right.
- 3) Using the grub screws (2) the door can be adjusted in and out.
- 4) After the door has been adjusted, the left side cladding and the hob can be reattached.

# 11.2 Adjusting the door spring




Fig. 48: Adjusting the closing pressure of the door

- 1) To adjust the door spring, the hob must be removed and only the left side cladding detached. Proceed as described in the section Removing the side cladding [on page 57].
- 2) At the bottom of the door there is a bolt which can used to adjust the door closing pressure. Use an open-end wrench to secure the bolt at the lower end (1).
- 3) Using a screwdriver, the closing pressure can be adjusted with the screw (2).
- 4) Reattach left side cladding and the hob.
- ⇒ Closing pressure is adjusted

# 12 Commissioning

## 12.1 Initial Commissioning

### **NOTICE**

During the initial commissioning and in the following 2-3 combustion cycles, only approx. 2/3 of the maximum fuel quantity is to be used.

#### **NOTICE**

To avoid damage you must **NEVER** operate your Stove a greater quantity of fuel than that specified in this manual!

During the first 3-4 combustion cycles at nominal heat output, odors may develop. The odors are caused by the evaporation of sheet metal greases and binding agents from the varnishing. Although unpleasant, these fumes are completely non-toxic. We therefore recommend that you well ventilate the room for the first few fires.

- 1) Remove all enclosed documents and appliance parts from the fireplace.
- 2) Read the operating manual through carefully before the initial commissioning.
  - ⇒ For optimally lighting we refer you to the section Making fire correctly.

### Removing the ash box cover

Before the stove is operated for the first time, it is absolutely vital to remove the cover of the ash box from the stove.

Proceed as follows: (for a better understanding, see also steps 1 and 2 in the section Emptying the ash box)

- 1) Open door.
- 2) Raise the grate with the hook supplied with the stove.
- 3) Take off the cover and lift it up.
  - ⇒ Cover is inserted incorrectly when delivered.
  - ⇒ You need the cover when you empty the ash box.
  - $\Rightarrow$  To empty the ash box we refer you to the section Emptying the ash box.

### 12.2 Balanced Flue Operation

The stove is generally approved as a balanced flue stove by the German Institute for Building Technology. If the combustion air is supplied directly to the fireplace from outdoors by means of a sealed pipe with a shut-off device, the stove may also be operated in utilization units with mechanical ventilation or ventilators.

If, however, the stove is used in this way, multiple occupancy of a chimney is not permitted.

The DIBT test applies to Germany

# 13 Operation

## 13.1 Before heating up

The stove can only function properly if there is sufficient combustion air coming to the room of installation (the appliance), specially if several firing installations are being operated at the same time. Ensure sufficient air supply before heating up. Open the combustion air flap on the stove and keep it open for the entire combustion period.

Devices for the supply of combustion air must not be modified.

# 13.2 Making fire correctly

To ensure the stove operates correctly and safely, it is important that the chimney generates the required draft. This must be checked in particular for each initial commissioning (e.g. after summertime) and in the transitional periods (e.g. when the wind is strong). If there is insufficient required draft, then paper or softwood chips can first be burnt in order to bring stove and chimney flue to temperature.

The air inlet of the stove must not be closed.




Fig. 49: Primary/secondary air controller

3 2 1

Fig. 50: Before kindling

- 1) Clean grate.
- 2) If necessary empty ash box (beware of embers).
- 3) Completely open the primary/secondary air control (1).
  - ⇒ Position "UP"

- 4) Lay 2-3 pieces of log (1) (beech, oak, birch) across the bottom of the firebox.
- 5) Finely split softwood above it (2).
- 6) Place a firelighter (3) in the middle and light it.
  - ⇒ Never use petrol, spirit or similar for ignition!

1	Log
2	Softwood
3	Firelighter

- 7) Close the door.
  - ⇒ It is best to allow the first layer of wood to combust without altering the air damper setting.
  - ⇒ If only the bed of embers is left (no more flames), you can place another layer of log.
- 8) When stoking up, proceed as for heating up:
  - ⇒ Open combustion air supply.
  - ⇒ Carefully open stove door.
  - ⇒ Put wood on.
  - ⇒ Close door.



Fig. 51: Flame pattern

- 9) As soon as the pieces of firewood are burning well all around (light, high flames), you can control the air supply with the controller.

  - the flames should always burn yellow and never blue or with black flame tips (otherwise feed more air in)

blue = too much air black = too little air

During combustion doe not totally close the air supply (danger of deflagration!).

# 13.3 Heating in the transition period

In the transition period, i.e. during high external temperatures, a sudden temperature rise can disrupt the chimney draft so that the fuel gases are not completely drawn off. In this case the appliance must be filled with smaller quantities of fuel and operated with the air damper/-controller on a higher setting so that the available fuel combusts more quickly (with a flame developing) and the chimney draft stabilized as a result.

# TIP

To prevent resistance in the firebed, the ashes should be removed more frequently.

# 14 Maintenance

# 14.1 Changing the seal on the door




Fig. 52: Changing the seal

- 1) Remove old seal from the door.
- 2) Glue in new seal with a suitable adhesive (e.g. silicon B310).
  - ⇒ Repeat these steps for the baking compartment door as well

# 15 Cleaning

# 15.1 Cleaning the stove, flue gas ducts and flue pipe

The stove, the flue gas ducts and flues should be annually - possible even more often, e.g.

- after the chimney has been cleaned
- checked for deposits
- cleaned as necessary.

### TIP

The chimney must likewise be regularly cleaned by the chimney sweeper. Your master chimney sweep will inform you of the necessary intervals. The stove should be inspected annually by a specialist

## 15.2 Emptying the ash box

- On a regular basis and in good time (at least 1 x per week) remove the ashes from the firebox and empty the ash box.
  - If the firebox is not regularly cleaned of ash then there is a danger that the combustion air openings become blocked and the appliance suffers damage.

To empty the ash box, proceed as follows:

# **NOTICE**

Be aware when emptying the ash box that there might be embers in the ash box. Only remove the ash box when the stove is in the cold state.




Fig. 53: Raising the grate

- 1) Open door.
- 2) Raise the grate with the attached hook.




Fig. 54: Putting the cover on the ash box




Fig. 55: Closing the cover




Fig. 56: Removing and emptying the ash box

- 3) Take the supplied cover and use it to cover the ash
- 4) Turn the handle of the cover clockwise until the handle engages.

- 5) Remove the ash box from the stove and empty it.
- 6) Reinsert the ash box after emptying it.
- 7) Close the grate again.

# 15.3 Cleaning the door window

Spray window with glass cleaner and leave it for a moment to take effect.

- We recommend cleaning the glass with our Austroflamm glass cleaner or a commercially available window cleaner.
- Prevent door- or window seals from coming into contact with water or cleaner, since these will otherwise harden and in doing so lose their function. Only intact seals ensure that your stove functions flawlessly.

### 15.4 Cleaning surfaces

- Varnished surfaces may only be cleaned with a soft cloth (if necessary damp).
- Soak up dissolved dirt with absorbent cloths or household paper.
- For stainless steel surfaces there are also special cleaners.

# 16 Help

Problem	Cause	Solution
The glass window is sooty	Insufficient draft	from time to time (depending on use) the window must be cleaned with glass cleaner
		Clarification with chimney sweeper (poss extend chimney/measure draft)
	incorrect operation of the air control	It is imperative that the air controller is operated in accordance with the instructions (if secondary air is closed too far, the glass pane will become sooty very quickly)
	excessively large pieces of firewood firewood too damp	Comply with quantity and size according to the instructions
	Operating temperature has not been reached	Use more fuel, dry wood (< 15 % residual moisture), pay attention to air regulation
The chimney is too small	The chimney draft is insufficient	Ask your chimney sweep to carry out a draft measurement
	Exhaust ducts and combustion chamber sooted up	Use more fuel, dry wood (< 15 % residual moisture), pay attention to air regulation
The stove emits a strong odor and smokes externally	Stove-enameling phase of the var- nish	During the first heating cycles, the varnish hardens and smells in the process
	The stove surface is dusty/soiled	Keep the surfaces of the stove clean
		Keep the floor area clean around the stove
Flue gas escapes when stoking up and during the heating phase	Chimney draft too low, flue pipe connection leaky	Check connection points and if necessary reseal
		Check chimney draft
	Door opened before combusted down to embers	Only stoke up when only embers are present (no more visible flames)
The fire is too weak and/or goes out	Air control closed (-)	Air control open (+)
	Wood too damp	Are you using dry wood (< 15 % residual moisture)?
	External temperature too high (>15 °C)	
The room is not warm enough	Convection air grille closed	Open convection air grille
	Chimney draft too high	Clarification with chimney sweeper (poss shorten chimney/measure draft)
The fire burns down too quickly and uncontrollably	Air control open (+)	Throttle combustion air supply after the operating temperature has been reached in the firebox (+ / -)
	Seals worn	Check whether the seals on the inside of the door are continuous and in working order, if necessary replace
	Firebox door not closed properly	Close firebox door
	Chimney draft too high	Clarification with chimney sweeper (poss shorten chimney/measure draft)
Ceramic windows become sooty very quickly	Unsuitable wood used	Use dry unrefined wood. See information about this in the Fuel section

Problem	Cause	Solution
	Operating temperature not reached	Bring stove to the operating temperature
		Sooting up of the window after 8-10 hours of fires is normal
	Chimney draft too low	Contact chimney sweep

## 16.1 Firebox lining

The lining of your stove consists of Keramott, a high-quality material with special combustion properties and an attractive appearance. During or after operation this lining may have superficial hairline cracks, which do not however affect functioning. Replacement of such parts is not required!

# 16.2 What to do in the event of a chimney fire

If fuel used is incorrect or too moist, then due to deposits in the chimney this may lead to a chimney fire.

- 1) Call the fire department and the district master chimney sweep!
- 2) Close the combustion air.
- 3) Enable access to the cleaning openings (e.g. basement and attic).
- 4) Remove all flammable material from the chimney.
- 5) Inform your district master chimney sweeper before recommissioning of your stove and have your chimney checked for any damage.

### 16.3 What to do in the event of faults

Should faults occur, your dealer will require the following details:

- Serial number and appliance model as per the nameplate
- Original invoice (date of sale)

# 17 Accessories

Have defective parts (accessories, spare parts) replaced by your specialist stove dealer. This guarantees that stove is and remains safe and functional.

### **Baking compartment**

The design is a fully functional baking compartment.

This baking compartment is heated from 4 sides (left, right, back and bottom).


### TIP

To achieve the most even possible cooking process, halfway through the cooking time you should turn the food being cooked.


The temperature in the baking compartment is regulated via the quantity of wood and the air controller. You can see the current temperature on the baking compartment thermometer (accessory).

The inside of the baking compartment is cleaned in the same way as other parts of the stove. Avoid greasy fumes, as these are difficult to clean.

# 18 Spare parts




ltem no.	Quantity	Item	Item no.
1	1	Keramott floor left	724691
2	1	Keramott floor rear	724692
3	2	Keramott panel side front	724693
4	2	Keramott panel side	724694
5	1	Keramott panel rear	724695
6	1	Keramott floor right	724696
7	1	Keramott deflection	724698
8	1	Keramott floor front	724699




Item no.	Quantity	Item	Item no.
1	1	HMS back left	724790
2	1	HMS left	724791
3	1	HMS right	724792
4	11	HMS holder	724793
5	1	HMS back right	724794

# Log drawer



Item no.	Quantity	Item	Item no.
1	4	M8-UT/FEF 3 BN4575	712712-93
2	4	Running wheel, complete	712794 3
3	2	Flat pot magnet (NdFeB)	717952 6
4	2	Counter-sunk head with hex M3x10	718605-92
5	1	Log drawer	724684-29

# Air+



Item no.	Qty	Item	ltem no.
1	2	Cheesehead bolts with socket head (very low head) M4x10	724701
2	1	Ring magnet DM10.1/9.5 H 6.4mm	724719
3	1	switch drive	724720
4	1	Airmaster Mainboard	724726
5	2	Universal joint with thread	724826
6	1	KS DC socket	724828
7	1	Power supply unit	724829
8	1	KS actuator AIR+	724930
9	1	Belimo anti-rotation clip	724880
10	1	AIR+ flame temperature sensor cable kit	728274
11	1	FTS	778675
12	1	Sensor tube, closed	779022
13	1	Cable binder 2,8x200	940274
14	1	Mounting instructions	718502-92
15	1	Counter-sunk head with hex M4x6	718539-92
16	2	Taptite SKS M5x8 718539-92	
17	2	Taptite ISR-LKS M3x5 718567-92	
18	4	Fillister-head screw with hex M3x5 718641-92	

Item no.	Qty	Item	Item no.
19	1	Driving plate	724689-92
20	1	Controller drive shaft 2	724702-92
21	1	Controller drive shaft 3	724703-92
22	1	Motor magnet adapter	724715-92
23	1	Aperture control unit	724716-29
24	1	Mainboard support sleeve	724717-29
25	1	Cover	724718-29
26	2	Spacer 5x7x6	772792-29

# 19 Dismantling

For correct uninstallation and dismantling of the stove, contact your Austroflamm specialist dealer.

# 19.1 Removing the side cladding




Fig. 57: Undoing the screws from above

1) Undo the marked screws from above.




Fig. 58: Undoing the screws on the inside




Fig. 59: Detaching the side cladding

2) Undo the screws on the inside at the bottom.

- 3) Detach the side cladding.
- 4) Repeat the last two steps to detach the side cladding on the other side.




Fig. 60: Undoing the screws on the left and right of the rear panel




Fig. 61: Detaching the rear panel

5) Undo the screws on the left and right of the rear panel

6) Detach the rear panel.

# 20 Disposal

#### **NOTICE**

To dispose of the stove properly, get in touch with the local (possibly municipal) waste disposal company.

### **NOTICE**

We recommend that you remove those components of the stove which have been in contact with fire such as window, combustion chamber, grates, firebox lining (Keramott), ceramic, sensors and baffle plates and dispose of them in the household waste.

#### **NOTICE**

For correct uninstallation and dismantling of the stove, contact your Austroflamm specialist dealer.

#### Electric and electronic components

Remove the electric and electronic components from the appliance by dismounting them. These components must not be disposed of via non-recyclable waste. Disposal should be carried out professionally via the electrical and electronic waste return system.

#### Keramott

Remove Keramott components. If present, fastening elements must be removed beforehand. Keramott components that have been in contact with fire or flue gas must be disposed of. Reuse or recycling is not possible. Local disposal options must be observed.

#### Steel sheet

Disassemble steel-sheet components of the appliance by mechanical crushing. If present, remove seals beforehand. Dispose of steel sheet parts as metal scrap. Local disposal options must be observed.

#### Cast iron

Disassemble cast-iron components of the appliance by unscrewing or flexing them from one another, or alternatively by mechanical crushing. If present, remove seals beforehand. Dispose of the cast-iron parts as metal scrap. Local disposal options must be observed.

#### Natural stone

Mechanically remove any natural stone present from the appliance and dispose of it as construction waste. Local disposal options must be observed.

#### Fittings etc. (for water-carrying appliances)

Disassemble the components for carrying water by unscrewing and removing them and dispose of them as metal scrap. Local disposal options must be observed.

### Seals (glass fiber)

Mechanically remove the seals from the appliance. These components must not be disposed of via non-recyclable waste as glass fiber waste cannot be destroyed through burning. Dispose of seals as glass- and ceramic fiber waste (artificial mineral fibers (AMF)). Local disposal options must be observed.

### Handles and decorative elements made of metal

If present, disassemble or remove handles and decorative elements made of metal and dispose of as metal scrap. Local disposal options must be observed.

# 21 Guarantee / warranty

1) Warranty statement: For your AUSTROFLAMM stove, we guarantee the flawless performance of the body for six years, and of all other steel and cast iron components for two years from the date of first sale.

Steel and cast-iron parts that manifest material- and or processing defects during the guarantee period (warranty case) will be replaced for new parts provided that the warranty case has been asserted to the best of the holder's knowledge within the statutory warranty period. Functional problems with electronic accessories (e.g. AIR+ automatic air control, etc.) shall only justify a warranty claim for the particular accessory.

Our warranty only covers the free delivery of the new parts: work- and travel times are not recorded.

2) **Exceptions:** We do not provide a guarantee on wearing parts (e.g. Keramott, seals and grate), surface coatings, varnish, glass and ceramics. In the case of such defects no warranty case has occurred.

When heating up, during operation and when cooling down, your stove may produce some noise (crackling, soft clicking, etc.). This is caused by the various materials expanding and contracting under the influence of temperature in your stove. Noise of this kind does not constitute a warranty claim and do not constitute a warranty claim.

The territorial scope of validity of our guarantee covers Austria, Germany and France. In all other countries, separate conditions of the importer apply to the respective country. No warranty case occurs if your Austroflamm stove is not located within the territorial scope of validity, which does not change if it is transported or dispatched by Austroflamm."

3) **Requirements:** A warranty case shall only then be replaceable if your Austroflamm stove has been operated, maintained, installed and commissioned by a specialist authorized by Austroflamm, all in compliance with the user handbook. For the replaceability of the warranty case the start-up log must be received by Austroflamm within one month at the latest of the initial commissioning. In order to make a claim on the warranty, repairs to your stove must only be carried out by a service engineer authorized by Austroflamm.

The warranty claim is asserted with the invoice and serial number with the Austroflamm specialist dealer via whom the purchase was made. An unjustified warranty claim will be charged back to you.

4) **Guarantee:** This guarantee does not affect your statutory warranty rights towards us. Should your Austroflamm stove already be defective at the point of handover, you can always connect us within the framework of the statutory warrant regardless of whether there is a warranty claim or the guarantee is claimed.

# 22 Data processing

### Additional commissioning report in respect of data processing

(please forward together with start up log and this page to info@austroflamm)

The personal data given in the start up log, in particular name, address, telephone number, which are solely necessary and required for the purpose of executing the start up of the product, are collected on the basis of legal authorizations.

Any use of the personal data beyond this and the collection of additional information usually requires the consent of the data subject. You may voluntarily grant such consent in the following section.

If you consent to the appropriate handling of your personal data for the following purposes, please tick this box.

o I hereby agree that Austroflamm GmbH and AUSTROFLAMM Service GmbH & Co KG may send me service reminders and offers on other products from Austroflamm GmbH for the purposes of advertising via E-Mail/ SMS/ telephone.

Signature		
Date:		

The legal instruction can be accessed on the Austroflamm GmbH home page at the following address: https://www.austroflamm.com/de/datenschutz.

# 23 Start up log

Operator / Customer	Dealer / Engineer
Name	Company
Street	Street
Town and postal code	Town and postal code
Telephone	Telephone
Email	Email

Stove	Working	Comments
Model		
Serial number		
Technology		
Visuals		
Accessories		

On-site conditions	
Type of chimney [ ] brick [ ] stainless steel [ ] firebrick	Flue pipe diameter:
Chimney diameter:	Draft: Actual value: Target value: >12 Pa
Chimney height:	Outside temperature during draft measurement:
Chimney flue - Approved by chimney sweep []yes[]no	External air supply conduit [ ] yes [ ] no
Controlled living space ventilation [] yes [] no	Length:

Instructions for Operator / Customer		
Instructions for handling the appliance explained clearly and comprehensibly	Appliance test heated together with the customer	
Guarantee conditions and warranty	Cleaning and maintenance interval explained	
explained		
[] glove [] operating manual handed over		

The customer confirms that the stove has been handed over in a fully functional state and free of defects.

Place, date	Signature Operator / Customer	Signature Technician

# 24 Service Report

Date	Technicians	Notes	Work carried out, replacement parts installed

Date	Technicians	Notes	Work carried out, replacement parts installed

Notizen / notes / app	unti / remarques		

 appunti / rema	arques ———		

Endkontrolle Final inspection Controllo finale Contrôle final	Typenschild (Duplikat) Type plate (duplicate) Targhetta (duplicato) Plaque signalétique (duplicata)
Technische Funktion technical function / funzione tecnica / fonction technique  Lackierung / paint / vernice / peinture	
Sauberkeit / cleanliness / pulizia / propreté	
Vollständigkeit / completeness / completo / complet  Geprüft von / checked by / controlled da / contrôlé par	
Datum / date / data / date	
Reprüffe Rualitä	

AUSTROFLAMM GMBH Austroflamm-Platz 1 A- 4631 Krenglbach

Tel: +43 (0) 7249 / 46 443 www.austroflamm.com info@austroflamm.com

