



Operating manual

Bono Xtra


AUSTROFLAMM

www.austroflamm.com

Operating manual

05/03/2024

Version: 2.0

LEGAL NOTICES

Owner and publisher

AUSTROFLAMM GMBH

Austroflamm-Platz 1

A- 4631 Krenglbach

Tel: +43 (0) 7249 / 46 443

www.austroflamm.com

info@austroflamm.com

Edited by: Olivera Stojanovic

Illustrations: Konstruktion

Text: Technical department (Austroflamm)

Copyright

All Rights reserved. The contents of these instructions may be reproduced or distributed only with the consent of the publisher! Printing, spelling and typographical errors reserved.

The information in this document is subject to change without prior notice and should not be construed as a commitment by Austroflamm GmbH. Austroflamm GmbH assumes no responsibility for any errors that may appear in this document.

Contents

| | | |
|----------|---|-----------|
| 1 | General information | 5 |
| 1.1 | Copyright..... | 5 |
| 1.2 | Information about the document | 5 |
| 2 | Purpose of the manual..... | 6 |
| 2.1 | Storing the manual | 6 |
| 2.2 | Structure of the manual..... | 6 |
| 2.3 | Representations used..... | 6 |
| 2.4 | Version control..... | 6 |
| 2.5 | Abbreviations | 7 |
| 3 | Safety..... | 8 |
| 3.1 | Importance of the safety instructions | 8 |
| 3.2 | General safety instructions | 8 |
| 3.3 | Special types of danger and personal protective equipment | 9 |
| 4 | Product overview..... | 10 |
| 4.1 | Intended use | 10 |
| 4.2 | Identification of the product..... | 10 |
| 4.3 | Energy label..... | 12 |
| 4.4 | Positioning of the nameplates | 12 |
| 5 | Technical data | 13 |
| 5.1 | Technical data according to Regulation (EU) 2015/1185 and delegated Regulation (EU) 2015/1186 | 13 |
| 5.2 | General specifications..... | 16 |
| 5.3 | Data for the chimney/flue dimensioning | 16 |
| 6 | Transport, handling and storage..... | 17 |
| 6.1 | Transportation..... | 17 |
| 6.2 | Transport brackets..... | 17 |
| 6.3 | Transport aid | 17 |
| 6.4 | Storage..... | 18 |
| 7 | Requirements at the installation location | 19 |
| 7.1 | Safety distances to be observed..... | 19 |
| 7.2 | Combustion air | 19 |
| 7.3 | Chimney requirements | 20 |
| 7.4 | Floor load-bearing capacity | 20 |
| 7.5 | Floor condition..... | 20 |
| 7.6 | Room of installation..... | 20 |
| 8 | Fuel material/-quantity | 21 |
| 8.1 | Fuel..... | 21 |
| 8.2 | Fuel quantity..... | 23 |
| 9 | Installation | 24 |
| 9.1 | Execution | 24 |

| | | |
|-----------|--|-----------|
| 9.1.1 | Rearranging the flue pipe connection | 24 |
| 9.1.2 | Installing the HMS..... | 26 |
| 9.1.3 | Installing the turntable | 29 |
| 10 | Settings | 33 |
| 10.1 | Adjusting the door | 33 |
| 10.2 | Adjusting the door lock | 34 |
| 10.3 | Adjusting the closing pressure of the door..... | 35 |
| 10.4 | Adjusting the fan..... | 35 |
| 11 | Commissioning | 36 |
| 11.1 | Initial Commissioning..... | 36 |
| 11.2 | Balanced Flue Operation..... | 36 |
| 12 | Operation..... | 37 |
| 12.1 | Before heating up..... | 37 |
| 12.2 | Making fire correctly..... | 37 |
| 12.3 | Heating in the transition period..... | 38 |
| 13 | Maintenance..... | 39 |
| 14 | Cleaning..... | 40 |
| 14.1 | Cleaning the stove, flue gas ducts and flue pipe | 40 |
| 14.2 | Removing ashes | 40 |
| 14.3 | Cleaning the door window | 40 |
| 14.4 | Cleaning surfaces | 40 |
| 15 | Help | 41 |
| 15.1 | Firebox lining | 42 |
| 15.2 | What to do in the event of a chimney fire..... | 42 |
| 15.3 | What to do in the event of faults..... | 42 |
| 16 | Accessories | 43 |
| 17 | Spare parts..... | 47 |
| 18 | Dismantling | 48 |
| 18.1 | Removing side cladding | 48 |
| 19 | Disposal..... | 49 |
| 20 | Guarantee / warranty | 51 |
| 21 | Start up log | 52 |
| 22 | Service Report..... | 53 |

1 General information

You have decided in favour of an Austroflamm stove.

Congratulations on your decision and thank you for your trust.

Correct operation and care are essential for trouble-free operation and long service life.

The information in this manual is of a general nature. National and European standards, local and building regulations, together with fire regulations must be complied with.

Read these instructions through carefully before installation and operation. No liability or warranty claims apply for damage incurred by failure to follow this manual.

Please observe the instructions in the individual sections.

This manual is a component part of the stove. It includes all the important information for both the dealer and the customer.

Personally hand over this manual to the owner of the stove together with an introduction to the system (heating operations).

In the following list we give you an overview of which sections are important for whom:

| Dealer | End customer |
|-----------------------|---|
| Complete instructions | General information |
| | Purpose of the manual |
| | Safety |
| | Product overview |
| | Technical data |
| | Requirements at the installation location |
| | Fuel material/-quantity |
| | Settings |
| | Commissioning |
| | Operation |
| | Maintenance |
| | Cleaning |
| | Help |
| | Accessories |
| | Spare parts |
| | Dismantling |
| | Disposal |
| | Guarantee / warranty |
| | Data processing |
| | Start up log |
| | Service Report |

1.1 Copyright

All Rights reserved. The contents of these instructions may be reproduced or distributed only with the consent of the publisher! Printing, spelling and typographical errors reserved.

1.2 Information about the document

The information in this document is subject to change without prior notice and should not be construed as a commitment by Austroflamm GmbH. Austroflamm GmbH assumes no responsibility for any errors that may appear in this document.

2 Purpose of the manual

This manual is a component part of the stove and is intended to contribute to the stove being safely installed and maintained.

TIP

Please read this manual before using the stove for the first time.

2.1 Storing the manual

Store this manual in case you need it. A current version of the manual can be found online at our homepage www.austroflamm.com.

2.2 Structure of the manual

The table of contents can be found on page 3.

Illustrations in this manual may differ from the delivered product.

2.3 Representations used

The following representations are used in this manual:

Steps with mandatory adherence to the sequence

✓ Prerequisite

1) Step 1

2) Step 2

3)

⇒ Intermediate result / additional information

⇒ Result

Steps and bullet points without mandatory sequence

•

•

-

-

Cross-references

See Technical Data

Useful tips

TIP

Fuel

Use only the recommended fuel!

2.4 Version control

We update our manuals on a continual basis. The current version can be found at our homepage www.austroflamm.com.

2.5 Abbreviations

| Abbreviation | Meaning |
|--------------|--------------------|
| HMS | Heat Memory System |
| ST | Stoves |

3 Safety

In this manual we give you numerous safety instructions for the safe operation of your stove. These instructions are characterized differently as follows, depending on their importance:

3.1 Importance of the safety instructions

NOTICE

Particular behaviour and/or activities that are required for safe working. Failure to follow this can result in material damage.

⚠ CAUTION

Possible dangerous situation (light or minor injuries and material damage).

⚠ WARNING

Possibly imminent danger to life and health of persons (severe injuries or death).

⚠ DANGER

Immediately imminent danger to life and health of persons (severe injuries or death).

3.2 General safety instructions

- The information in this manual represents generally applicable standards and rules. National and European standards, local and building regulations, together with fire regulations must also be complied with.
- Before operating your stove, carefully read through the entire manual and observe the instructions and warnings.
- Austroflam GmbH accepts no liability or responsibility for the connection of our heating appliances to shared exhaust pipes/chimneys – **multiple occupancy**. For more information consult a chimney sweep and check your national, regional and local building regulations.
- Only approved transport aids with sufficient load-bearing capacity may be used to transport your stove.
- Caution - varnish is not an anti-rust protection!
- Burn only the fuel listed and approved in the section.
- It is strictly forbidden to burn or introduce highly flammable or explosive substances, such as empty aerosols and the like, into the firebox or to store them in the immediate vicinity of your stove due to the risk of explosion.
- No loose or easily flammable items of clothing should be worn when laying the fire.
- Please note that placing non-heat-resistant objects on, or near, the stove is forbidden.
- Do not place any items of laundry on the stove to dry. Laundry racks or the like must be placed at a sufficient distance from the stove. – (Fire hazard!)
- This stove is not a slow-burn fire.
- While your stove is in operation, it is forbidden to process highly flammable or explosive substances in the same room or in adjoining rooms.
- The stove must only be operated with the doors closed.
- The door and all the stove's control devices must be closed when the stove is not in operation.

- Please note that the surfaces of this stove heat up considerably during operation. We recommend that you use the protective glove supplied to operate your stove.



- Please alert children to these dangers, and keep them away from the stove when it is operating.

⚠ DANGER



Danger of overheating

To prevent damage you must **NEVER** operate your stove with a greater quantity of fuel than the quantity given in these instructions, either during its initial commissioning or every time you subsequently light it up again!

- Your stove is not suitable for use as a ladder or a stand.
- Waste materials (of any kind) or residues **MUST NOT** be burned in the stove.
- When working on or with the stove, always wear protective gloves. Example: moving the stove, assembling, disassembling, repairing, attaching accessories, etc.
- Sharp edges may be created during or after the installation of accessory parts. Please use suitable grinding or cutting tools to remove these sharp edges.

3.3 Special types of danger and personal protective equipment

For certain activities such as installation/dismantling, particular care must be taken that the following safety equipment is worn:

| | |
|---|---------------|
|  | Safety gloves |
|  | Safety shoes |

4 Product overview

4.1 Intended use

The Austroflamm stove described in this manual is manufactured and tested with a type A1 self-closing and locking door under EN 13240.

NOTICE

Operation is only permissible with closed/bolted door.

4.2 Identification of the product

In the following illustrations we give an overview of the most important dimensions and the nameplate positioning.






Fig. 1: Basic appliance dimensions



- 1) OPEN - CLOSED - primary- secondary air damper
- 2) OPEN - CLOSED - riddling grate slider

Fig. 2: Primary air damper and riddling grate slider



- 3) OPEN - CLOSED - convection air damper

Fig. 3: Convection air damper

Safety distances




Fig. 4: Safety distances

4.3 Energy label




Fig. 5: Energy label

4.4 Positioning of the nameplates

Here we show where you can find the type plate. You received a copy of the type plate with the stove. You can find a copy of the type plate of your stove on the back of the manual you get with your stove.

The type label is located on the rear of the stove.




Fig. 6: Nameplate

5 Technical data

As a type 1 stove, a connection to a chimney already occupied with other solid-fuel stoves and ovens is possible provided that the chimney rating under DIN 4705 – part 3, does not contravene this.

5.1 Technical data according to Regulation (EU) 2015/1185 and delegated Regulation (EU) 2015/1186

Contact details for the manufacturer or their authorised representative

| | |
|---------------|--------------------|
| Manufacturer: | Austroflam GmbH |
| Contact: | - |
| Address: | Austroflam-Platz 1 |
| | 4631 Krenglbach |
| | Austria |

Appliance details

| | |
|---|-------------------------|
| Model identification(s): | Bono Xtra |
| Equivalent models: | - |
| Test reports: | 1625 / RRF - 40 11 2750 |
| Applied harmonized standards: | EN 13240 |
| Other standards/technical specifications. Specifications: | |
| Indirect heating function: | No |
| Direct heat output: | 5.0 |
| Indirect heat output ¹ : | - |

Properties for operation with the preferred fuel

| | |
|--|------|
| Space heating annual use efficiency η_s : | 70.1 |
| Energy efficiency index (EEI): | 106 |

Particular precautions for assembly, installation or maintenance

Described in the individual sections of the operating manual.

| Fuel | Preferred fuel (only one) ² : | Other suitable fuel(s) ³ : | η_s [%]: | Space heating emissions at nominal heating efficiency (*) | | | | Space heating emissions at minimum heat output ⁴ (*) (**) | | | |
|--|---|---------------------------------------|------------------|---|-----|------|-----------------|--|-----|----|-----------------|
| | | | | PM | OGC | CO | NO _x | PM | OGC | CO | NO _x |
| | | | | [x] mg/Nm ³ (13% O ₂) ⁵ | | | | [x] mg/Nm ³ (13% O ₂) ⁶ | | | |
| Log, moisture content \leq 25 % | yes | no | 70.1 | 21 | 86 | 1000 | 141 | - | - | - | - |
| Compregnated laminated wood, moisture content < 12 % | no | no | - | - | - | - | - | - | - | - | - |
| Other woody biomass | no | no | - | - | - | - | - | - | - | - | - |
| Non-woody biomass | no | no | - | - | - | - | - | - | - | - | - |
| Anthracite and dry steam coal | no | no | - | - | - | - | - | - | - | - | - |
| Coking coal | no | no | - | - | - | - | - | - | - | - | - |
| Semi-coke | no | no | - | - | - | - | - | - | - | - | - |
| Bituminous coal | no | no | - | - | - | - | - | - | - | - | - |
| Lignite briquettes | no | no | - | - | - | - | - | - | - | - | - |
| Peat briquettes | no | no | - | - | - | - | - | - | - | - | - |
| Briquettes made from a mixture of fossil fuels | no | no | - | - | - | - | - | - | - | - | - |
| Other fossil fuels | no | no | - | - | - | - | - | - | - | - | - |
| Briquettes made from mixture of biomass and fossil fuels | no | no | - | - | - | - | - | - | - | - | - |
| Other mixture made of biomass and solid fuels | no | no | - | - | - | - | - | - | - | - | - |

(*) PM = dust, OGC = organic gaseous connections, CO = carbon monoxide, NO_x = nitrogen oxide

(**) Only required when using correction factors F(2) or F(3).

Properties for exclusive operation with the preferred fuels⁷

| Specification | Symbol | Value | Unit | Specification | Symbol | Value | Unit |
|--|--------------------|-------|------|--|---------------------|-------|------|
| Heat output | | | | Thermal efficiency (fuel efficiency) (based on the NCV) | | | |
| Nominal heat efficiency | P _{nom} | 5.0 | kW | Thermal efficiency (fuel efficiency) at nominal heat efficiency | η _{th,nom} | 80.1 | % |
| Minimum heat output (standard value) | P _{min} | - | kW | Thermal efficiency (fuel efficiency) at minimum heat output (standard value) | η _{th,min} | - | % |
| Auxiliary power consumption | | | | Type of heat output/room temperature control | | | |
| At nominal heat efficiency | el _{max} | - | kW | single-level heat output, no room temperature control | | | yes |
| At minimum heat output | el _{min} | - | kW | two or more manually adjustable levels, no room temperature control | | | no |
| In standby condition | el _{SB} | - | kW | room temperature control with mechanical thermostat | | | no |
| Pilot flame power requirement | | | | with electronic room temperature control | | | no |
| Pilot flame power requirement (if present) | P _{pilot} | - | kW | with electronic room temperature control and day-time regulation | | | no |
| | | | | with electronic room temperature control and weekday regulation | | | no |
| | | | | Other regulation options (multiple selections possible) | | | |
| | | | | room temperature control with presence detection | | | no |
| | | | | room temperature control with open window detection | | | no |
| | | | | with remote control option | | | no |

¹ There is no entry for fireplaces without water-carrying components.

² Values for annual use efficiency and emissions must be given here for the preferred fuel.

³ Values for annual use efficiency and emissions must be given here for all other suitable fuels.

⁴ Corresponds to partial load heat output as per EN 16510

⁵ Specification in mg/m³ for heated filter method (in compliance with Annexe III, number 4, letter a, section i, point 1) or g/kg for measurement in dilution tunnel (in compliance with Annexe III, number 4, letter a, section i, point 2 and 3.)

⁶ Specification mg/m³ for heated filter method (in compliance with Annexe III, number 4, letter a, section i, point 1) or g/kg for measurement in dilution tunnel (in compliance with Annexe III, number 4, letter a, section i, point 2 and 3.)

⁷ Specifications must be made here for the preferred fuel only.

5.2 General specifications

| Dimensions and weight | |
|---|------|
| Height [mm] | 1150 |
| Width [mm] | 462 |
| Depth [mm] | 441 |
| Combustion chamber width [mm] | 282 |
| Combustion chamber height [mm] | 452 |
| Combustion chamber depth [mm] | 259 |
| Baking compartment width [mm] | - |
| Baking compartment height [mm] | - |
| Baking compartment depth [mm] | - |
| Warming drawer, width [mm] | - |
| Warming compartment height [mm] | - |
| Warming drawer, depth [mm] | - |
| Dimensions, a (with Austroflam elbow piece) [mm] | 1679 |
| Dimensions, b (with Austroflam elbow piece) [mm] | 1000 |
| Dimensions, c (with Austroflam elbow piece) [mm] | 614 |
| Dimensions, d (with Austroflam elbow piece) [mm] | 200 |
| Flue pipe outlet, diameter [mm] | 150 |
| Outside air connection diameter [Ø mm] | 125 |
| Weight, basic appliance [kg] | 219 |
| Weight Xtra [kg] | 107 |
| Weight, HMS [kg] | - |
| Total weight inc. steel case (STM) [kg] | 237 |
| Total weight inc. ceramic case (KGM) [kg] | - |
| Total weight inc. soapstone case (SPM) [kg] | 310 |
| a: Safety distance to combustible materials, front [mm] | 900 |
| b: Safety distance to combustible materials, left [mm] | 270 |
| c: Safety distance to combustible materials, rear [mm] | 160 |
| d: Safety distance to combustible materials, right [mm] | 270 |
| Safety distance to combustible materials, floor [mm] | 0 |
| Minimum distance from non-flammable materials [mm] | 50 |
| Output | |
| Nominal heat efficiency [kW] | 5.0 |
| Minimum heat output [kW] | 2.5 |
| Maximum heat output [kW] | 7.0 |
| Minimum room heating capacity [m³] | 48 |
| Maximum room heating capacity [m³] | 124 |
| Energy efficiency class | A |

5.3 Data for the chimney/flue dimensioning

Exhaust gas values for the multiple occupancy of the chimney (according to DIN 4705 Part 3) or rating of the chimney (according to DIN 4705 Part 2)

| Data for the chimney sweep | |
|---|-----|
| Exhaust gas mass flow [g/s] | 4.2 |
| Flue gas temperature [°C] | 322 |
| Minimum delivery pressure at nominal heat output [Pa] | 12 |
| at 0.8 times nominal heat output [Pa] | 10 |

6 Transport, handling and storage

6.1 Transportation



Fig. 7: Crate

Immediately checked the goods delivered for completeness and damage in transit.

Before installing the stove, check that all movable parts are working. Any defects before the installation of the stove must be reported.

Transport is with a crate. The crate facilitates transport of the stove using a lifting truck or forklift.

Remove the crate and dispose of it appropriately.

6.2 Transport brackets

NOTICE

It is vital that the transport lock screws are removed before the appliance is installed!




Fig. 8: Removing the transport lock

For transportation the stoves are in addition fixed to the pallet with transport locks. These must be removed before installation.

- 1) Undo the screws and remove the transport locks.

6.3 Transport aid




Fig. 9: Transport aid

Only approved transport aids with sufficient load-bearing capacity may be used for transport. These must be removed before installation.

6.4 Storage

The stove must be stored in a dry room/warehouse. Protect against dirt, heat and moisture.

The following illustrations are attached to the crate and must be observed:



- Fragile - always place upright - protect against moisture and store dry.



- Remove and dispose of packing material in an environmentally friendly manner.



- The crate can be disposed of in the separate collection for packaging. Local disposal regulations must be observed.

7 Requirements at the installation location


7.1 Safety distances to be observed

If your floor is made of a combustible material, a non-combustible material must be used as protection in the area in front of the appliance. For more detailed information, please contact an Austroflamm dealer.

NOTICE

A floor protection plate must be used if your floor is made from a combustible material.

Safety distances for combustible objects, such as wooden furniture, upholstered furniture, sofas, etc. must be complied with. In the case of very heat-sensitive objects the distance from the stove must be increased in order to avoid damage from the heat.



Safety distances to be observed (minimum distances – see also type plate).

Fig. 10: Safety distances (view from above)
up

| | |
|---|-----|
| a: Safety distance to combustible materials, front [mm] | 900 |
| b: Safety distance to combustible materials, left [mm] | 270 |
| c: Safety distance to combustible materials, rear [mm] | 160 |
| d: Safety distance to combustible materials, right [mm] | 270 |
| Safety distance to combustible materials, floor [mm] | 0 |

7.2 Combustion air

An adequate supply of combustion air must be provided during operation. With a modern very thick building shell it can happen that the combustion air supply is not guaranteed for balanced flue operation or that the draft behaviour is impaired. In this case an adequate supply of combustion air must be provided. Your Austroflamm specialist dealer will be happy to advise you.

TIP

Ensure that combustion air openings are not closed!

7.3 Chimney requirements

When connecting the flue pipes to the chimney, national and/or local safety regulations must be complied with. Your Austroflamm stove is fitted at the factory with a flue pipe outlet at the top (see chapter Technical data). The connection can, as described in these instructions, be rearranged to the bottom. When connecting with other pipe diameters the approval of your responsible chimney sweep is required. The flue pipe connection and flue pipe transitions must be sealed accordingly. Your Austroflamm specialist dealer knows the guidelines and will be happy to advise you. For your own safety the connection of the flue pipe must be carried out by a technically competent person.

7.4 Floor load-bearing capacity

Before installing, verify whether the load-bearing capacity of the substructure can withstand the weight of your Austroflamm stove.

With regards to loading capacity, for floors with underfloor heating we refer you to your structural engineer responsible for statical calculations, builder, etc.

7.5 Floor condition

Austroflamm stoves can be placed directly on the floor.

The fire protection regulations for operating a wood-burning or pellet stove vary depending upon the location and appliance. We recommend you obtain this information from your chimney sweep or the specialist dealer in your area.

7.6 Room of installation

Note that the room in which the stove is installed must have at least one door / one window leading to the outside, or be directly connected to such a room. For balanced flue operation, other heating appliances and extractor hoods must not be operated together with this heating appliance as part of the room air system.

8 Fuel material/-quantity

8.1 Fuel

Wood

Many of our native types of wood can, after being appropriately dried, be burnt CO₂-neutral in heat-producing appliances. Wood stands out because it grows again, can be sustainably harvested, requires little or no extra external energy to be invested in the fuel, and has a short journey from the producer to the consumer, which provides an optimal climate balance.

The most common types of wood to use in the stove are beech, yoke elm, birch, larch, spruce and pine. The most important criterion for burning in a heat-producing appliance is that the fuel has been sufficiently dried through. For this purpose the prepared pieces of firewood should be stored for at least two years. The legislator stipulates a maximum water content of 20%. That is still however a lot of water sitting in the capillaries of the wood. A piece of firewood only becomes good when its water content comes to a maximum of 12 to 13%. The differences in combustion behavior are striking and clearly detectable even by the layman.

Types of wood other than the ones referred to above are also suitable for burning. However each heat-producing appliance should be checked for how their use affects combustion behavior. Oak for example burns with a rather shorter flame and more embers. Oakwood catches fire with greater difficulty, and due to hardness of the wood it is not split as well (small) as other types of wood, which again has a negative effect on combustion behavior. It is however a good energy source, and, correctly processed, also suitable as firewood.

Softwoods (fir, pine, spruce) should if possible be mixed with hardwood. Softwoods have a higher proportion of tannin, which leads to more deposits in the heat-producing appliance, the connecting pipes and the chimney. If only softwood is burnt, this can lead more quickly to a build-up of shining soot. Mixing with hardwood (for example, beechwood) reduces this effect.

The size of your heat-producing appliance's combustion chamber will dictate whether your firewood is 25cm, 33cm or 50cm in length. 50cm pieces of firewood should preferably dry for somewhat longer (laid down for three years or more), because wood is dried out mainly by the leakage of water from the capillaries - and that simply takes time. And the path from inside to outside in a 50cm-long piece of firewood is twice as long as in a 25cm-long piece of firewood. The important thing is that the wood is well split. This means that the circumference of a piece of firewood (once all sides are measured around the cutting point) must be a maximum of 15-25cm. Pieces of wood cut to this size dry more easily - above all, however, they give the fire (the temperature) a greater attack area and thus make it easier to evolve gas and thus to burn. Also the quantity of fuel can be better measured out. Thanks to their outstanding levels of efficiency, modern heat-producing appliances require just a fraction of the amount of wood of earlier stoves. Here smaller pieces of firewood can be placed according to the manufacturer's specifications - large pieces of wood often exceed the maximum specified quantity with just a single piece.

Not everyone has a hygrometer at home for determining the water content in wood, particularly when good reliable units cost several hundred euros. However you can make a good estimate of how suitable your fuel is by carefully observing combustion behavior. A "good" wood fire will only smoke briefly in the ignition phase, hardly at all after that. It will burn with a light (yellow to orange-colored) long flame. Little residue will occur in the combustion chamber, most of it disappearing again when the fire is fully developed. Another good criterion for assessing whether a piece of firewood is suitable for combustion is its weight. Most manufacturers also specify the amount to be laid in kg/weight. Example: a piece of beechwood 33cm in length with a circumference of approx. 20cm weighs approx. 1kg when it is suitable (dry enough) for burning. Therefore 25cm in length gives approx. 750 grammes, and 50 cm in length approx. 1.5kg.

Please observe at all times the maximum specified amount to be laid, even when putting on more wood! Otherwise your fire will not provide the desired efficiency - but above all considerable damage may be caused to your appliance, to gaskets and material and to the flue gas duct.

The wood may only be burnt untreated. NEVER burn treated woods, not even wood processed with natural substances or organic glazes. Wood waste does not belong in the stove!

Wood briquettes

Many people like wood briquettes as a fuel because they require less storage space than wood, can be stocked or sold in small quantities and - at least at first glance - make less work than wood. Within the scope of production, the quality of briquettes is consistent. Wood briquettes do not need to be stored for a long time to be dried out. Due to the raw material (unrefined chips) and the production process they have an already defined residual moisture.

If wood briquettes are designated as a suitable fuel, then this still only applies to this fuel, NOT for coal-, paper-, bark- or other pressed items, such as pellets.

In spite of various standardizations and many advertising promises, there are also considerable differences in quality in wood briquettes. But even with good fuel quality, combustion behavior is different from that of unrefined log. And not every wood briquette burns equally well in every stove. Before you decide on a particular variety and perhaps even store this up in larger quantities, you should extensively test the wood briquettes under various draft conditions. Most suppliers keep "test packages" for this purpose that can be purchased at preferential prices to test out and compare with one another the various types offered.

TIP

When burning wood briquettes, the maximum quantity specified in these instructions must also be observed. The quantity must not be exceeded.

As the wood is pressed and thus has little spatial volume for the same weight, modern heat-producing appliances with a low placement quantity often have "little fire heaps" occur, leading one to wonder whether a fire can burn at all with so little fuel. Nevertheless you must never exceed the maximum placement, because that would cause damage. Many wood briquettes change during the temperature increase when burning, by "opening up". This should not worry you as it is normal. When inserting wood briquettes make sure that this expansion as far as possible does not press not in the direction of the window, as otherwise this will get very dirty.

In principle you should not insert wood briquettes as one piece, but rather break them at the layer thicknesses, which are usually visible in slices, and place smaller pieces in the combustion chamber, not in an interlocking manner, but randomly. This way you will ensure that the combustion air reaches more burning material and flows around it better. Wood briquettes require a stronger air current, an expert eye and perhaps a bit more patience, until you get the knack of it. Since less volume is available (although the same mass, it takes less space up), the fire is generally smaller and does not burn so high and vivaciously as when burning log. When wood briquettes alone are burnt, this therefore generally leads to haziness in the combustion chamber, as well as on the stove window. Not all areas of the combustion chamber have the same temperature applied to them as when unrefined wood is burnt, which is why these deposits occur. It may be that with one variety of wood briquettes more deposits occur, whereas with another variety none at all. This suggests trying out various varieties to determine the suitable fuel for your heat-producing appliance. If you would really like to use wood briquettes, but don't get on quite well with them, then it may also help to mix the fuel. That means: Burn wood briquettes and unrefined log in the mixture ratio that achieves a good burning result for your heat-producing appliance.

Wood briquettes must also be stored dry. In general it can be said that pressed items with a hole in the middle usually burn better. Soft wood briquettes are to be preferred and are often more suitable than hard wood briquettes.

Approved fuel

Dry, properly stored, unrefined log (preferably hard wood) is permitted as fuel for our stoves.

Round wood must be split at least once so that it lights better. The diameter of the split piece of wood must not exceed 7 cm.

Explosive substances

It is strictly forbidden to burn or introduce highly flammable or explosive substances (empty aerosols and the like) into the firebox or to store them in the immediate vicinity of your stove. Risk of explosion!

Fuel

Only burn the recommended fuel.

Clean combustion

The firewood must be dry (rel. wood moisture < 15 %) and untreated. Furthermore the correct quantity of firewood must be burnt in order to achieve a clean, low-emission combustion.

8.2 Fuel quantity

Maximum fuel quantity

Your Austroflamm stove is designed for maximum efficiency: see Technical Data section. Too great a quantity of fuel can lead to overheating and damage to your Austroflamm stove!

Maximum amount of fuel to be deposited: 1.5 kg wood.

NOTICE**Overheating**

Too great a quantity of fuel can lead to overheating and damage to your Austroflamm stove

NOTICE

To avoid damage you must **NEVER** operate your Stove a greater quantity of fuel than that specified in this manual!



9 Installation

Installation must only be carried out by an authorized specialist company.
Before installing the stove, check that all movable parts are working. Any defects must be reported before the installation.

In the following sections we will give you information on

- the integration or attachment of appliance parts
- the rearrangement of the flue pipe connection
- The connection of the combustion air supply, and on
- other important facts relating to the installation.

The protective equipment and tools listed are required for the following work steps

| Type of protective equipment | |
|--|---------------|
|  | Safety gloves |
|  | Safety shoes |

| Work equipment | Activity |
|-----------------|---|
| Insulated tools | In order not to damage or scratch the varnish, no sharp objects or tools should be used. Instead insulated tools are used by preference when assembling and disassembling stove parts. |
| Torx wrench set | Various installation jobs |
| Allen key set | Various installation jobs |
| Fork wrench set | Various installation jobs |

9.1 Execution

9.1.1 Rearranging the flue pipe connection




Fig. 11: Detaching the cover

- 1) Detach cover.




Fig. 12: Removing the screws from the rear panel




Fig. 13: Removing the perforated cut-out




Fig. 14: Removing the heat shield




Fig. 15: Removing cover and flue pipe bracket

- 2) On the rear, loosen the screws at the bottom.
- 3) Pull rear panel upwards and outwards.

- 4) Use a saw to remove the perforated cut-out (back).

- 5) If necessary, slightly turn the fan (1).
- 6) Slide the heat shield (2) outwards and upwards.

- 7) Remove cover on the back.
- 8) Remove flue pipe bracket.




Fig. 16: Replacing cover and bracket




Fig. 17: Cover and bracket replaced

- 9) Replace parts and reinstall.
- 10) Remount rear panel and attach cover.

9.1.2 Installing the HMS

First the cover and the side cladding must be detached. Proceed as described in the section Removing the side cladding [► on page 48].




Fig. 18: Removing the screws from the rear panel

- 1) On the rear, loosen the screws at the bottom.
- 2) Pull rear panel upwards and outwards.




Fig. 19: Undoing the screws from the fan

3) Undo the screws (1) from the fan.




Fig. 20: Removing the heat shield

4) Carefully lift up the fan (1).

5) Slide the heat shield (2) outwards and upwards.




Fig. 21: Installing the HMS mountings

6) Fit the HMS mountings at the rear and sides to the already mounted screws.




Fig. 22: Attaching the HMS bricks

- 7) Attach HMS bricks to the HMS mountings and fasten with the screw at the top.




Fig. 23: Attaching the clip band

- 8) Place the clip band (1) above the top HMS bricks loosely connect with the turnbuckle (2) (do not completely tighten).




Fig. 24: Inserting upper HMS bricks

- 9) Insert the upper HMS bricks and pull the turnbuckle somewhat tighter by turning it.




Fig. 25: Fitting side cladding

- 10) Refit the side cladding.
- 11) Reinstall and adjust the fan. In doing so, proceed as described in the section Adjusting the fan [► on page 35].
- 12) Attach cover.

9.1.3 Installing the turntable




Fig. 26: Detaching the cover

- 1) Detach cover.




Fig. 27: Removing the flue pipe bracket

- 2) Remove flue pipe bracket.




Fig. 28: Attaching the seal to swivel elbow coupling

3) Attach seal to the swivel elbow coupling




Fig. 29: Fitting the swivel elbow coupling

4) Fit swivel elbow coupling.




Fig. 30: Detaching the connection part

5) Detach the connection part on the back.




Fig. 31: Mounting the connection part on the turntable

6) Mount the connection part at the bottom on to the turntable.




Fig. 32: Tilting the stove

For this step it is recommended to work in pairs.

- 7) Carefully tilt the stove backward.




Fig. 33: Removing the sealing plate from below

- 8) Remove the sealing from below.




Fig. 34: Mounting the sealing plate

- 9) Mount the sealing plate at the back from where the connection part was removed.




Fig. 35: Placing the seal adapter

- 10) Place the seal adapter on to the turntable.




Fig. 36: Installing the turntable




Fig. 37: Turning the stove

- 11) Using two people, carefully tilt the stove backward.
- 12) Slide the turntable under the stove.
 - ⇒ In doing so, take care that the seal adapter fits accurately into the stove's cut-out.
- 13) Set the stove upright again.

- 14) To turn the stove, release the lever upwards that is located at the back of the stove at the bottom and turn the stove into the desired position.

10 Settings

10.1 Adjusting the door

- 1) To adjust the door, first the cover must be removed and only the left side cladding detached. Proceed as described in the section Removing the side cladding [▶ on page 48].
- 2) Open door.
- 3) The door can be adjusted on the screws.
- 4) Using the screws (1) the door can be adjusted up, down, left and right.
- 5) Using the grub screw (2), the door can be adjusted in and out.




Fig. 38: Door adjustment screws

- 6) After the door has been adjusted, the side cladding and the cover can be reattached.
- ⇒ Door is adjusted.

10.2 Adjusting the door lock

- 1) To adjust the door lock, first the cover must be removed and only the right side cladding detached. Proceed as described in the section Removing the side cladding [► on page 48].
- 2) Open door.




Fig. 39: Open door




Fig. 40: Adjusting the door lock

- 3) Using the marked screws, the hinges can be adjusted so that it fits with the lock on the door.

10.3 Adjusting the closing pressure of the door




Fig. 41: Adjusting the closing pressure of the door

- 1) Open the lower front door.
 - ⇒ At the bottom of the door there is a spring which can be used to adjust the door closing pressure.
 - 2) Use an open-end wrench to secure the bolt at the lower end (1).
 - 3) Using a screwdriver, the closing pressure can be adjusted with the screw (2).
 - 4) Remount front cladding and side cladding and attach cover.
- ⇒ Closing pressure is adjusted

10.4 Adjusting the fan

The fan can be adjusted horizontally and vertically.




Fig. 42: Fan from above




Fig. 43: Screws for adjustment

Horizontal adjustment:

- 1) Loosen the four screws (a) above the fan.
- 2) Adjust the fan.
- 3) Retighten screws (a).

Vertical adjustment:

- 4) Loosen the four screws (a) above the fan.
- 5) Use the four screws (b) below the fan to adjust the height.
- 6) Retighten the four screws (a) above the fan.

11 Commissioning

11.1 Initial Commissioning

NOTICE

During the initial commissioning and in the following 2-3 combustion cycles, only approx. 2/3 of the maximum fuel quantity is to be used.

NOTICE

To avoid damage you must **NEVER** operate your Stove a greater quantity of fuel than that specified in this manual!

During the first 3-4 combustion cycles at nominal heat output, odors may develop. The odors are caused by the evaporation of sheet metal greases and binding agents from the varnishing. Although unpleasant, these fumes are completely non-toxic. We therefore recommend that you well ventilate the room for the first few fires.

- 1) Remove all enclosed documents and appliance parts from the fireplace.
- 2) Read the operating manual through carefully before the initial commissioning.
 - ⇒ For optimally lighting we refer you to the section Making fire correctly.

11.2 Balanced Flue Operation

For balanced flue operation, the stove must be fed directly from the outside to the fireplace via an air-tight duct with barrier. This way the stove can also be operated in units with mechanical airing or ventilation. This applies to all countries except Germany. In Germany an additional test is required.

12 Operation

12.1 Before heating up

The stove can only function properly if there is sufficient combustion air coming to the room of installation (the appliance), specially if several firing installations are being operated at the same time. Ensure sufficient air supply before heating up. Open the combustion air flap on the stove and keep it open for the entire combustion period.

Devices for the supply of combustion air must not be modified.

12.2 Making fire correctly

To ensure the stove operates correctly and safely, it is important that the chimney generates the required draft. This must be checked in particular for each initial commissioning (e.g. after summertime) and in the transitional periods (e.g. when the wind is strong). If there is insufficient required draft, then paper or softwood chips can first be burnt in order to bring stove and chimney flue to temperature.

The air inlet of the stove must not be closed.




Fig. 44: Primary- secondary air damper and riddling grate slider



Fig. 45: Before kindling

- 1) Clean grate.
- 2) If necessary empty ash pan (beware of embers).
- 3) Completely open the primary/secondary air damper (1).
⇒ Position "UP"
- 4) Pull riddling grate slider (2) completely forward.

- 5) Lay 2-3 pieces of log (1) (beech, oak, birch) across the bottom of the firebox.
- 6) Finely split softwood above it (2).
- 7) Place a firelighter (3) in the middle and light it.
⇒ Never use petrol, spirit or similar for ignition!

| | |
|---|-------------|
| 1 | Log |
| 2 | Softwood |
| 3 | Firelighter |

- 8) Close the door.
 - ⇒ It is best to allow the first layer of wood to combust without altering the air damper setting.
 - ⇒ If only the bed of embers is left (no more flames), you can place another layer of log.
- 9) When stoking up, proceed as for heating up:
 - ⇒ Open combustion air supply.
 - ⇒ Carefully open stove door.
 - ⇒ Put wood on.
 - ⇒ Close door.
- 10) As soon as the pieces of firewood are burning well all around (light, high flames), you can control the air supply with the controller.
 - ⇒ Control at maximum setting = maximum heat output
 - ⇒ the flames should always burn yellow and never blue or with black flame tips (otherwise feed more air in).
 - blue = too much air
 - black = too little air
 - ⇒ During combustion do not totally close the air supply (danger of deflagration!).



Fig. 46: Flame pattern

To prevent the escape of fuel gases, always keep the firebox door closed during heating operation. The riddling grate does not need to be activated during the heating process. It is only required for conveying ashes into the ash pan - when the stove is not burning.

12.3 Heating in the transition period

In the transition period, i.e. during high external temperatures, a sudden temperature rise can disrupt the chimney draft so that the fuel gases are not completely drawn off. In this case the appliance must be filled with smaller quantities of fuel and operated with the air damper/-controller on a higher setting so that the available fuel combusts more quickly (with a flame developing) and the chimney draft stabilized as a result.

TIP

To prevent resistance in the firebed, the ashes should be removed more frequently.

13 Maintenance

Have the maintenance carried out by an Austroflamm dealer or an Austroflamm service engineer.

14 Cleaning

14.1 Cleaning the stove, flue gas ducts and flue pipe

The stove, the flue gas ducts and flues should be annually - possible even more often, e.g.

- after the chimney has been cleaned
- checked for deposits
- cleaned as necessary.

TIP

The chimney must likewise be regularly cleaned by the chimney sweeper. Your master chimney sweep will inform you of the necessary intervals. The stove should be inspected annually by a specialist

14.2 Removing ashes

NOTICE

Please note that when removing the ashes, embers may still be present. Only remove the ashes from the firebox when the stove is in the cold state.

- On a regular basis and in good time (at least 1 x per week) remove the ashes from the firebox.
 - If the firebox is not regularly cleaned of ash then there is a danger that the combustion air openings become blocked and the appliance suffers damage.
- 1) Open the door.
 - 2) Remove ashes with a shovel and brush or with an ash vacuum cleaner.

14.3 Cleaning the door window

Spray window with glass cleaner and leave it for a moment to take effect.

- We recommend cleaning the glass with our Austroflamm glass cleaner or a commercially available window cleaner.
- Prevent door- or window seals from coming into contact with water or cleaner, since these will otherwise harden and in doing so lose their function. Only intact seals ensure that your stove functions flawlessly.

14.4 Cleaning surfaces

- Varnished surfaces may only be cleaned with a soft cloth (if necessary damp).
- Soak up dissolved dirt with absorbent cloths or household paper.
- For stainless steel surfaces there are also special cleaners.

15 Help

| Problem | Cause | Solution |
|---|---|---|
| The glass window is sooty | Insufficient draft | from time to time (depending on use) the window must be cleaned with glass cleaner Clarification with chimney sweeper (poss extend chimney/measure draft) |
| | incorrect operation of the air regulator | It is imperative that the air regulator is operated in accordance with the instructions (if secondary air is closed too far, the glass pane will become sooty very quickly) |
| | excessively large pieces of log log too damp | Comply with quantity and size according to the instructions |
| | Operating temperature has not been reached | Use more fuel, dry wood (< 15 % residual moisture), pay attention to air regulation |
| The chimney is too small | The chimney draft is insufficient | Ask your chimney sweep to carry out a draft measurement |
| | Exhaust ducts and combustion chamber sooted up | Use more fuel, dry wood (< 15 % residual moisture), pay attention to air regulation |
| The stove emits a strong odor and smokes externally | Stove-enameling phase of the varnish | During the first heating cycles, the varnish hardens and smells in the process |
| | The stove surface is dusty/soiled | Keep the surfaces of the stove clean Keep the floor area clean around the stove |
| Flue gas escapes when stoking up and during the heating phase | Chimney draft too low, flue pipe connection leaky | Check connection points and if necessary reseal Check chimney draft |
| | Door opened before combusted down to embers | Only stoke up when only embers are present (no more visible flames) |
| The fire is too weak and/or goes out | Air regulator closed (-) | Air regulator open (+) |
| | Wood too damp | Are you using dry wood (< 15 % residual moisture)? |
| | External temperature too high (>15 °C) | |
| The room is not warm enough | Convection air grille closed | Open convection air grille |
| | Chimney draft too high | Clarification with chimney sweeper (poss shorten chimney/measure draft) |
| The fire burns down too quickly and uncontrollably | Air regulator open (+) | Throttle combustion air supply after the operating temperature has been reached in the firebox (+ / -) |
| | Seals worn | Check whether the seals on the inside of the door are continuous and in working order, if necessary replace |
| | Firebox door not closed properly | Close the firebox door |
| | Chimney draft too high | Clarification with chimney sweeper (poss shorten chimney/measure draft) |
| Ceramic windows become sooty very quickly | Unsuitable wood used | Use dry unrefined wood. See information about this in the Fuel section |

| Problem | Cause | Solution |
|---------|-----------------------------------|---|
| | Operating temperature not reached | Bring stove to the operating temperature |
| | | Sooting up of the window after 8- 10 hours of fires is normal |
| | Chimney draft too low | Contact chimney sweep |

15.1 Firebox lining

The lining of your stove consists of Keramott, a high-quality material with special combustion properties and an attractive appearance. During or after operation this lining may have superficial hairline cracks, which do not however affect functioning. Replacement of such parts is not required!

15.2 What to do in the event of a chimney fire

If fuel used is incorrect or too moist, then due to deposits in the chimney this may lead to a chimney fire.

- 1) Call the fire department and the district master chimney sweep!
- 2) Close the combustion air.
- 3) Enable access to the cleaning openings (e.g. basement and attic).
- 4) Remove all flammable material from the chimney.
- 5) Inform your district master chimney sweeper before recommissioning of your stove and have your chimney checked for any damage.

15.3 What to do in the event of faults

Should faults occur, your dealer will require the following details:

- Serial number and appliance model as per the nameplate
- Original invoice (date of sale)

16 Accessories

Have defective parts (accessories, spare parts) replaced by your specialist stove dealer. This guarantees that stove is and remains safe and functional.




Fig. 47: Convection air control

Xtra heat storage technology

Your stove is equipped with the unique Xtra heat storage technology. This is based on the patented Heat Memory System, but also on the special flue gas duct and the controllable convection air that can even be shut off. Thus a rapid heating system is combined with exceptional heat storage.

You can control the convection air as needed with the associated controller (1). The more convection air openings are open in the cover, the quicker but shorter-lasting heat will be achieved. On the other hand a closed cover leads to slower warming up and a longer output of heat.

TIP

While the fire is burning, leave the convection air open and closed it afterwards in order to achieve a long even emission of heat.

Accessories






Fig. 48:

| Item no. | Quantity | Item | Item no. |
|----------|----------|------------------------------------|-----------|
| 1 | 1 | Basic appliance, complete | 066001 |
| 2 | 1 | Turntable set complete Ø150 | 059007 |
| 3 | 1 | Steel cladding, complete | 066002 |
| 4 | 1 | Cast iron top plate, complete | 066003-29 |
| 5 | 1 | Soapstone cladding, complete | 066005 |
| 6 | 1 | Seal adapter | 719067-29 |
| 7 | 1 | Elbow piece 150 - set | 620067 |
| 8 | 1 | Sandstone cover, complete | 066009 |
| 9 | 2 | Transport aid, complete | 361224 |
| 10 | 1 | WALL DISTANCE wall distance sketch | - |

HMS

| Item no. | Quantity | Item | Item no. |
|----------|----------|--------------------------------------|-------------|
| 1 | 1 | HMS, rear | 719341 HMS |
| 2 | 2 | HMS, side | 719342 HMS |
| 3 | 1 | HMS, front top | 719343 7 |
| 4 | 2 | HMS top | |
| 5 | 2 | Large diameter washer for M8 DIN9021 | 718324-92 |
| 6 | 2 | Large diameter washer for M6 DIN9021 | 718131-92 |
| 7 | 2 | Taptite hex. LKS M6X40 DIN7500C | 718609-92 |
| 8 | 2 | HMS mounting | 718825-95 |
| 9 | 4 | HMS mounting | 717962-95 |
| 10 | 1 | Clip band | 719389-95 0 |
| 11 | 1 | Turnbuckle (hook) M6 DIN1480 | - |

Keramott



| Item no. | Quantity | Item | Item no. |
|----------|----------|------------------------|----------|
| 1 | 1 | Keramott rear panel | 719346 |
| 2 | 1 | Keramott panel left | 719347 |
| 3 | 1 | Keramott panel right | 719348 |
| 4 | 1 | Keramott wood retainer | 719345 |
| 5 | 1 | Keramott tension plate | 719408 |
| 6 | 1 | Keramott baffle plate | 719349 |

17 Spare parts

Spare parts can be ordered through our dealers.

18 Dismantling

For correct uninstallation and dismantling of the stove, contact your Austroflamm specialist dealer.

18.1 Removing side cladding




Fig. 49: Detaching the cover

1) Detach cover.




Fig. 50: Detaching the side cladding

2) Lift up and detach the side cladding.

19 Disposal

NOTICE

To dispose of the stove properly, get in touch with the local (possibly municipal) waste disposal company.

NOTICE

We recommend that you remove those components of the stove which have been in contact with fire such as window, combustion chamber, grates, firebox lining (Keramott), ceramic, sensors and baffle plates and dispose of them in the household waste.

NOTICE

For correct uninstallation and dismantling of the stove, contact your Austroflam specialist dealer.

Electric and electronic components

Remove the electric and electronic components from the appliance by dismantling them. These components must not be disposed of via non-recyclable waste. Disposal should be carried out professionally via the electrical and electronic waste return system.

Keramott

Remove Keramott components. If present, fastening elements must be removed beforehand. Keramott components that have been in contact with fire or flue gas must be disposed of. Reuse or recycling is not possible. Local disposal options must be observed.

Steel sheet

Disassemble steel-sheet components of the appliance by mechanical crushing. If present, remove seals beforehand. Dispose of steel sheet parts as metal scrap. Local disposal options must be observed.

Cast iron

Disassemble cast-iron components of the appliance by unscrewing or flexing them from one another, or alternatively by mechanical crushing. If present, remove seals beforehand. Dispose of the cast-iron parts as metal scrap. Local disposal options must be observed.

Natural stone

Mechanically remove any natural stone present from the appliance and dispose of it as construction waste. Local disposal options must be observed.

Fittings etc. (for water-carrying appliances)

Disassemble the components for carrying water by unscrewing and removing them and dispose of them as metal scrap. Local disposal options must be observed.

Seals (glass fibre)

Mechanically remove the seals from the appliance. These components must not be disposed of via non-recyclable waste, as glass fibre waste cannot be destroyed through burning. Dispose of seals as glass- and ceramic fibre waste (artificial mineral fibres (AMF)). Local disposal options must be observed.

Handles and decorative elements made of metal

If present, disassemble or remove handles and decorative elements made of metal and dispose of as metal scrap. Local disposal options must be observed.

20 Guarantee / warranty

- 1) **Warranty statement:** For your AUSTROFLAMM stove, we guarantee the flawless performance of the body for six years, and of all other steel and cast iron components for two years from the date of first sale.

Steel and cast-iron parts that manifest material- and or processing defects during the guarantee period (warranty case) will be replaced for new parts provided that the warranty case has been asserted to the best of the holder's knowledge within the statutory warranty period. Functional problems with electronic accessories (e.g. AIR+ SmartSpot) shall only justify a warranty claim for the particular accessory.

Our warranty only covers the free delivery of the new parts: work- and travel times are not recorded.

- 2) **Exceptions:** We do not provide a guarantee on wear parts (e.g. Keramott, seals), surface coatings, varnish, glass and ceramics. In the case of such defects no warranty case has occurred .

When heating up, during operation and when cooling down, your stove may produce some noise (crackling, soft clicking, etc.). This is caused by the various materials expanding and contracting under the influence of temperature in your stove. Noise of this kind does not constitute a warranty claim and do not constitute a warranty claim.

The territorial scope of validity of our guarantee covers Austria and Germany. In all other countries, separate conditions of the importer apply to the respective country.

No warranty case occurs if your Austroflamm stove is not located within the territorial scope of validity, which does not change if it is transported or dispatched by Austroflamm."

- 3) **Requirements:** A warranty case shall only then be replaceable if your Austroflamm stove has been operated, maintained, installed and commissioned by a specialist authorized by Austroflamm, all in compliance with the user handbook. For the replaceability of the warranty case the start-up log must be received by Austroflamm within one month at the latest of the initial commissioning. In order to make a claim on the warranty, repairs to your stove must only be carried out by a service engineer authorized by Austroflamm.

The warranty claim is asserted with the invoice and serial number with the Austroflamm specialist dealer via whom the purchase was made. An unjustified warranty claim will be charged back to you.

- 4) **Guarantee:** This guarantee does not affect your statutory warranty rights towards us. Should your Austroflamm stove already be defective at the point of handover, you can always connect us within the framework of the statutory warrant regardless of whether there is a warranty claim or the guarantee is claimed.

21 Start up log

| Operator / Customer | Dealer / Engineer |
|----------------------|----------------------|
| Name | Company |
| Street | Street |
| Town and postal code | Town and postal code |
| Telephone | Telephone |
| Email | Email |

| Stove | Working | Comments |
|---------------|---------|----------|
| Model | | |
| Serial number | | |
| Technology | | |
| Visuals | | |
| Accessories | | |

| On-site conditions | |
|--|---|
| Type of chimney [] brick [] stainless steel [] firebrick | Flue pipe diameter: |
| Chimney diameter: | Draft: Actual value: Target value: >12 Pa |
| Chimney height: | Outside temperature during draft measurement: |
| Chimney flue - Approved by chimney sweep [] yes [] no | External air supply conduit [] yes [] no |
| Controlled living space ventilation [] yes [] no | Length: |

| Instructions for Operator / Customer | | |
|--|--|--|
| Instructions for handling the appliance explained clearly and comprehensibly | Appliance test heated together with the customer | |
| Guarantee conditions and warranty explained | Cleaning and maintenance interval explained | |
| [] glove [] user instructions handed over | | |

The customer confirms that the stove has been handed over in a fully functional state and free of defects.

Place, date

Signature Operator / Customer

Signature Technician

22 Service Report

| Date | Technicians | Notes | Work carried out, replacement parts installed |
|------|-------------|-------|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Date | Technicians | Notes | Work carried out, replacement parts installed |
|------|-------------|-------|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

AUSTROFLAMM GMBH
Austroflamm-Platz 1
A- 4631 Krenglbach

Tel: +43 (0) 7249 / 46 443
www.austroflamm.com
info@austroflamm.com

945062

